

Part number: 14288-6E-30

Language: English

Date: 2009-04-17


**This manual covers the following machine:**

## 1450 Injector

Serial No.: \_\_\_\_\_.

Voltage/Hz: \_\_\_\_\_.

Amperage: \_\_\_\_\_.



**Stork Townsend Inc.**

2425 Hubbell Avenue | Des Moines, IA 50317 USA  
N. America: 800 247-8609 | Intl.: 515 265-8181 | Fax: 515 263-3355  
[www.townsendeng.com](http://www.townsendeng.com)

**Stork Townsend B.V.**

Industrielaan 63 - 5349 AE Oss | P.O. Box 292 - 5340 AG Oss | The Netherlands  
Telephone: +31 (0)412 669 911 | Fax: +31 (0)412 669 250  
[www.townsend.nl](http://www.townsend.nl)

© Copyright 1995-03 Stork Townsend Inc.

## TABLE OF CONTENTS

<b><i>Subject</i></b>	<b><i>Page</i></b>	<b><i>Subject</i></b>	<b><i>Page</i></b>
<b>Section 1 – Safety</b> .....	5 thru 11	<b>Section 7 – Parts List</b> .....	101
<b>Section 2 – Installation</b> .....	13	How to Use Parts List .....	102
General Description .....	15	To Place an Order .....	103
Overall Dimensions .....	16	Cross Reference .....	104
Electrical Supply .....	17	Cabinet – RH Controls .....	109
Air Supply .....	19	Cabinet – LH Controls .....	111
Fluid Supply .....	19	Conveyor Drive .....	113
Installation & Start–up .....	21	Conveyor Stroke Linkage .....	115
Daily Safety Circuit Test .....	25	Pump Drive .....	117
<b>Section 3 – Operation</b> .....	27	Conveyor (Metal Belt) .....	119
Machine Controls .....	29	Conveyor Guards (Metal Belt) ...	121
Operating Instructions .....	32	Conveyor (Plastic Belt) .....	123
<b>Section 4 – Cleaning</b> .....	37	Conveyor Guards (Plastic Belt) ..	125
<b>Section 5 – Maintenance</b> .....	47	Head Carriage .....	127
Preventive Maintenance .....	49	Head & Valve (RB10/15) .....	129
Lubrication Instructions .....	50	Head & Valve (RB30) .....	131
Overhaul Instructions .....	54	Pump (RB10/15) .....	133
Variable Stroke Linkage .....	57	Pump (RB30) .....	135
Conveyor Speeds .....	57	Fluid Hoses .....	137
Control Valve .....	59	Electrical System .....	143
Stripper Stops .....	61	Air System .....	149
Fluid Hoses .....	63	Tags .....	153
Filter Screens .....	65	Filter Unit (Model 11) .....	155
Conveyor Drive .....	67	Stripper Stops (Optional) .....	159
Conveyor .....	73	Infeed Tray .....	160
Head Carriage .....	77	Infeed Rollers .....	161
Stripper .....	79	Exit Table .....	162
Pump – Preventive Maintenance .	83	Casters .....	163
Pump – Overhaul .....	85	Hardware Items .....	164
Air System .....	91	<b>Index</b> .....	170
Fluid System .....	93		
Electrical System .....	94		
<b>Section 6 – Troubleshooting</b> .....	95		
Check These First .....	97		
Problems & Causes .....	98		



# SECTION 1 SAFETY

## — Contents —

Attention! .....	7
Supervisors .....	7
To All Users .....	8
Safety Instructions .....	9
Safety Precautions .....	10
Safety Specifications .....	11



**Read instructions and review safety information (pages 5 through 11) before using or servicing the machine.**



## ATTENTION!

**Read and understand this manual. This is an obligation for all who use or maintain this machine, and for all who supervise its use.**



**This symbol is used in this manual to indicate specific safety precautions.**

### **Supervisors:**

Make sure copies of this manual are provided to all who will use or maintain this machine. A training program should be instituted to ensure material contained in this manual is understood and followed by all. Training should be repeated periodically to reinforce safe procedures.

When the machine is relocated or sold, this manual must also be supplied to the new user. Additional copies and translations are available from:

Stork Townsend Inc.  
2425 Hubbell Avenue,  
Des Moines, IA 50317 USA

N. America: 800 247-8609  
Intl. 515 265-8181  
Fax: 515 263-3355

[www.townsendeng.com](http://www.townsendeng.com)

Stork Townsend B.V.  
Industrielaan 63 - 5349 AE, Oss, The Netherlands  
P.O. Box 292 - 5340 AG, Oss, The Netherlands

Telephone: +31 (0)412 669 911  
Fax: +31 (0)412 669 250

[www.townsend.nl](http://www.townsend.nl)

Use this machine only for purpose for which it was designed and intended. Do not alter its design. Use only genuine Stork Townsend repair parts or accessories.

### **Airborne noise**

The noise pressure level emitted by this machine: . . . . . 83 dB(A)  
(calculated at the operator position, according to ISO 11204)

You must wear hearing protection when operating this machine.

**See more safety information on the following pages.**

**To All INSTALLERS  
OPERATORS,  
MAINTENANCE PERSONNEL, AND  
CLEAN-UP PERSONNEL.**

**Read and understand all instructions and safety precautions, especially the following:**

- 1. Start machine only if you are completely ready to run the machine.**

Lock out electrical supply to machine if there is risk of injury from unexpected start of machine, or if there is possibility of electrical shock.

“**Lock out**” means the electrical supply required to run the machine is positively prevented from reaching the machine by using a lockable type switch.

Stop operation immediately if machine malfunctions, or if operating conditions are unsafe.

- 2. Keep hands and clothing away from sharp edges, and from any moving parts.**

Stay alert. Keep eyes on hands and product zone while working. Do not force product or machinery – allow machine to do the work it is intended to do.

Stop operation if you are not physically able to be alert, or do not have required strength or agility to operate machine safely. Do not operate at speed that hinders safe operation.

**Also read and understand the instructions and precautions on the following pages.**



## SAFETY INSTRUCTIONS

1. Read and follow this manual before installing, operating, cleaning, or servicing this machine.
2. Before operating this machine, verify that all safety features are working correctly (see page 25).
3. Report any malfunctions immediately to supervisor.
4. Malfunctions of safety devices must be corrected before operating the machine. If machine is operating abnormally, clear instructions must be provided for safe handling of the equipment until abnormal conditions are corrected.
5. Operate this machine only after being trained for its correct and safe operation. Training should be repeated at regular intervals.
  - a. Keep hands and clothing clear of all moving parts.
  - b. Do not contact any sharp edges.
  - c. Keep hands and clothing clear of injector head, and conveyor drive crank arms while electrical supply is connected to machine.
  - d. Allow conveyor to carry product to needle zone – do not force product.
  - e. Read and follow completely the cleaning instructions listed in this manual.
  - f. During investigation of any problem, if injury could result from unexpected start of machine, or if there is possibility of electrical shock, make sure electrical supply is locked out (see page 8).
6. Use this machine only for purpose for which it was designed and intended. Do not alter its design. Use only genuine Stork Townsend repair parts or accessories.



**If machine malfunctions during use, stop use of machine immediately. Notify supervisor immediately.**

**Also read and understand precautions on the following page.**

## SAFETY PRECAUTIONS

- Do Not** install or operate this machine in any manner or for any purpose different from that for which it was designed and intended.
- Do Not** connect electrical supply until machine is completely assembled and installed, and all guards, covers, safety devices, and other parts are properly installed.
- Do Not** operate machine until daily safety circuit test has been performed (see page 25).
- Do Not** service, repair, adjust, or investigate any problem until electrical supply is locked out (see page 8) if injury could result from unexpected start of machine, or if there is possibility of electrical shock.
- Do Not** operate machine with any damaged, missing, or malfunctioning parts or safety devices.
- Do Not** modify or remove any parts or safety devices, or substitute parts not intended for use on this machine.
- Do Not** press or force product into needle zone.
- Do Not** contact sharp edges. Handle needles with extreme care. Dispose of needles properly and safely.
- Do Not** reach inside guards or covers while machine is running, or contact any moving parts.
- Do Not** leave machine energized while unattended.




**If machine malfunctions during use, stop machine immediately. Notify supervisor immediately.**

## SAFETY SPECIFICATIONS SHEET


### Main Disconnect Switch – Q1

Stork Townsend #: 18733  
 Manufacturer: Entrelec  
 Manufacturer's #: 9001002  
 Contacts: 4 Normally-open  
 20 A at 600 VAC  
 4 kW at 220 VAC; 7.5 kW at 380 VAC




### Inlet Guard Interlock Switch – S9

Stork Townsend #: 18563  
 Manufacturer: Elobau  
 Manufacturer's #: 120 271  
 Contacts: magnetic reed switches  
 1 Normally-closed; 1 Normally-open  
 150 mA at 1-70 V




### Hood Interlock Switch – S6

Stork Townsend #: 18563  
 Manufacturer: Elobau  
 Manufacturer's #: 120 271  
 Contacts: magnetic reed switches  
 1 Normally-closed; 1 Normally-open  
 150 mA at 1-70 V



### Side Panel Interlock Switches – S7, S8, S10

Stork Townsend #: 18563  
 Manufacturer: Elobau  
 Manufacturer's #: 120 271  
 Contacts: magnetic reed switches  
 1 Normally-closed; 1 Normally-open  
 150 mA at 1-70 V





# SECTION 2 INSTALLATION


## — Contents —

General Description .....	15
Overall Dimensions .....	16
Electrical Supply .....	17
Air Supply .....	19
Fluid Supply .....	19
Installation & Start-up .....	21
Daily Safety Circuit Test .....	25



**Read instructions and review safety information (pages 5 through 11) before operating machine.**

## General Description



## GENERAL DESCRIPTION

The Model 1450 Injector is designed to inject wide variety of meat products with variety of product-enhancing fluids. Small diameter, closely spaced injecting needles, combined with precision fluid control system provide even and accurate distribution of fluid.

(Note: Illustration callout numbers will appear throughout this manual to coordinate the text to illustrations. The first part of the number is the illustration number, and the second part is the callout sequence within the particular illustration. For example, [1-5] refers to callout number 5 on illustration number 1.)


The primary elements of the Model 1450 are the fluid system, the conveyor, and the safety system. Various options are available to customize the machine for special products or for special production arrangements.

The **fluid system** consists of a pump [1-16], a filter unit [1-1], a control valve [1-12], and the injecting needles [1-13]. The pump is driven by a separate pump motor [1-3]. Pump is available in several choices to match injection rate requirements. The filter unit will catch and filter runoff fluid. The filter unit can function as a fluid reservoir, or may be connected to a centralized fluid distribution system. The control valve is linked to a sensing mechanism that meters fluid flow according to product size, providing accuracy of injection percentages, and minimizing fluid waste. The amount of fluid that is delivered thru the needles per stroke is adjustable. The needles are carried by an injecting head that drives needles into the product. Needles are small to prevent product damage, and spacing is close to provide uniform injection. Needles automatically retract when they contact bones.

The **conveyor system** consists of a drive motor [1-2], a conveyor belt [1-15], and a head carriage [1-14]. The head carriage carries the needles to and from the product. A stripper plate [1-6] is built into the head carriage to help control the fluid valve, and to strip product off the needles. A clutch [1-4] coordinates conveyor movement with head carriage so that conveyor belt advances while head carriage is up, and stops while head carriage is down. The amount of belt movement per stroke is adjustable.

The **safety system** incorporates a system of guards (hood, inlet guard, and side covers [1-8][1-9][1-10]) that are interlocked electrically to stop conveyor drive when guards are not properly installed. The control circuit is designed so that the drive mechanism will not automatically restart when the guards are put back in place. To restart, the operator must first put all guards back in place, then use the drive start switch [1-5] to run the machine again. The control circuit also incorporates a self-checking feature that will prevent restarting if a control switch has its contacts stuck in the on position. This safety system does not, however, interrupt the pump motor.

## Overall Dimensions





## Utility Requirements

### ELECTRICAL



**All wiring and connections for this machine must comply with applicable national and local electrical codes.**

Table below lists motor voltage and amperage requirements for the Model 1450. The machine must be properly grounded. Electrical supply must have a disconnect switch. Overload protection for the motor is incorporated into the machine.

#### Pump Motor – 3 Phase

190V–50Hz–5hp—————18.5A

200V–50Hz–5hp—————17.0A

200V–60Hz–5hp—————17.5A

208V–60Hz–5hp—————13.9A

220V–50Hz–5hp—————14.0A

230V–60Hz–5hp—————15.2A

380V–50Hz–5hp—————8.1A

380V–60Hz–5hp—————8.1A

415V–50Hz–5hp—————8.0A

460V–60Hz–5hp—————7.6A

575V–60Hz–5hp—————6.1A

#### Conveyor Drive Motor – 3 Phase

190V–50Hz–1-1/2hp—————5.5A

200V–50Hz–1-1/2hp—————5.2A

200V–60Hz–1-1/2hp—————4.5A

208V–60Hz–1-1/2hp—————4.2A

220V–50Hz–1-1/2hp—————4.2A

230V–60Hz–1-1/2hp—————3.8A

380V–50Hz–1-1/2hp—————2.5A



380V–60Hz–1-1/2hp—————2.5A

415V–50Hz–1-1/2hp—————2.3A

460V–60Hz–1-1/2hp—————1.9A

575V–60Hz–1-1/2hp—————2.0A

## Utilities



### AIR SUPPLY

Air pressure assists control of three functions of the Model 1450: (1) Air pressure controls fluid pressure to the needles by means of an accumulator feature in the fluid control valve. (2) Air pressure to the stripper controls the amount of force created to strip product off the needles (3) Two air cylinders counterbalance the weight of the head carriage.

Use flexible hose and relieving type quick disconnect fitting to connect air supply to inlet filter [2-10] on right side of cabinet (1/4-18 NPT female thread). Separate filters and pressure regulators supply each air circuit [2-7][2-8][2-9]. Supply pressure should be at least 100 psi (690 kPa). Filters have auto-drain feature to eliminate moisture. Check that moisture is not accumulating. Replace filter elements as needed.

If using with the Model 11 Filter Unit, air consumption is 15–70 CFM (7–33 L/sec), depending on filter drum speed.


### FLUID SUPPLY

Replenish fluid supply must meet or exceed actual pump usage – maximum output of RB10 pump is approximately 10 gpm (38 L/min), RB15 is 15 gpm (57 L/min), RB30 is 30 gpm (114 L/min). Supply pressure to Model 11 should not exceed 75 psi (515 kPa). Connect replenish supply line to port [2-16] on side of Model 11 filter unit (3/4-14 female thread).



**This is a wet process – provide adequate drainage.**

## Installation



## INSTALLATION



**Read instructions and review safety information (pages 5 through 11) before assembling, installing, and operating machine. Do not connect electrical supply until machine is completely assembled.**

Utility requirements and physical dimensions are given on pages 16 thru 19. Machine is wired for voltage specified in your order. A tag [3-22] attached to power cord identifies voltage and amperage requirements.


### Installation

1. With machine in suitable work area, adjust legs [3-24] so machine is stable.
2. Connect fluid hoses – see page 63.
3. Position 11 filter unit [3-1] so rotary strainer [3-12] will catch fluid from runoff trough [3-13]. Adjust filter support screws so tank is stable.
4. Install filter screens [3-17] (see page 65). Fill tank – pump will be damaged if pump is run dry, if fluid is hot, or if granules are not fully dissolved.
5. Make sure fluid control valve [3-18] is properly adjusted (see page 59), and conveyor variable stroke linkage [3-15] is set as desired (see page 57).
6. Make sure all guards and covers [3-14][3-16][3-21] are installed or closed. Remove all loose objects from machine.
7. Connect electrical supply.
8. Turn main disconnect switch [3-20] on. Pull control switch [3-9] on – knob will light. Caution: Light is added as a convenience to indicate power is on – do not depend on absence of light to mean power is off, since light bulb is a consumable item and could be burned out.



**To stop machine, push in knob on control switch. Machine will also stop when an interlocked guard is moved, or main disconnect switch is turned off.**

## Installation



9. Connect air supply and set pressure regulators as follows:

Fluid System . . . . . [4-6] Varies with product – for example, lower for seafood, higher for red meats. Higher pressure will give higher injection percentages.

Stripper Cylinders . . [4-7] Varies with product – set as low as possible while preserving stripping action, that is, machine still pulls product off needles.

Assist Cylinders . . . . [4-8] 40 psi (275 kPa).


Air Motor – Model 11 [4-11] Set pressure as low as possible, but high enough to maintain smooth operation and desired speed. Lower pressure will consume less air.

10. Check adjustment of stripper stops [4-20] (optional equipment). If product is delicate, make sure the stripper is stopped above the point where product damage would begin. The left and right stops should be level with each other (see page 61).

11. Press drive start pushbutton [4-5] to run conveyor and head carriage.

12. Check direction of rotation of crank arms [4-15] – labels on machine indicate proper direction. If incorrect, stop machine, lock out electrical supply (see page 8), and switch two leads of main power supply to the machine. Reconnect and recheck drive rotation.

## Installation





### 13. Perform Daily Safety Circuit Test.

#### Daily Safety Circuit Test

1. With machine running, machine must stop immediately when:
  - a. Inlet guard [5-18] is raised.
  - b. Hood [5-15] is raised.
  - c. Side covers [5-23] are removed.
  - d. Control switch [5-10] is pushed in.
  - e. Main disconnect switch [5-22] is turned off.
2. Machine must not restart when guards are returned to run position unless motor start buttons are pushed – restarting must only occur by pushing start button after guards are in run positions.

14. To run product, press pump start pushbutton [5-11]. Open bleed valve [5-2] until all air bubbles are eliminated from fluid lines. Close valve.

15. Press drive start pushbutton [5-6]. Lay product on inlet end of conveyor.



**Notify supervisor immediately for repair of any problem.**



**Do not leave machine energized while unattended.**



# **SECTION 3 OPERATION**


**— Contents —**

Controls .....	29
Operating Instructions .....	32
Quick Reference Sheet – Operation/Cleaning .....	35



**Read instructions and review safety information (pages 5 through 11) before operating machine.**

## Machine Controls



## OPERATION OF MODEL 1450



**Read instructions and review safety information (pages 5 through 11) before operating machine.**

### Machine Controls

MAIN DISCONNECT SWITCH [6-6]. Rotate to “0” position for off, “1” position for on. Switch controls high voltage to motor contactor and to transformer for 24 volt control circuit. Use this switch to lock out electrical supply during maintenance (see page 8).

CONTROL SWITCH [6-4]. Pull on, push off. Switch turns on 24 volt control circuit. Knob will light when power is on. Caution: Light is added as a convenience to indicate power is on – do not depend on absence of light to indicate power is off, since light bulb is a consumable item and could be burned out.


DRIVE START [6-3]. Press pushbutton to start drive motor – motor will continue running.

DRIVE STOP [6-2]. Press pushbutton to stop drive motor.

PUMP START [6-5]. Press pushbutton to start pump motor – motor will continue running.

PUMP STOP [6-1]. Press pushbutton to stop pump motor.

## Machine Controls



## OPERATION OF MODEL 1450

### Machine Controls – continued

REGULATOR – FLUID PRESSURE [7-1]. Turn knob clockwise to increase air pressure controlling fluid injection pressure.

REGULATOR – STRIPPER PRESSURE [7-2]. Turn knob clockwise to increase air pressure to stripper cylinders. Adjust for type of product and for target injection percentage – higher pressure = higher injection percentage. Set as low as possible while keeping stripping action, that is, machine still pulls product off needles.

REGULATOR – ASSIST CYLINDERS [7-3]. Turn knob clockwise to increase air pressure to assist cylinders supporting head carriage. Set at approximately 40 psi (275 kPa).

REGULATOR – AIR MOTOR [7-4]. Set pressure as low as possible, but high enough to maintain smooth operation and desired speed. Lower pressure will consume less air.

BLEED VALVE [7-6]. Pull “T” handle out to open valve. Leave open until all air disappears from fluid system – look for air bubbles in transparent hoses. Lock valve closed by positioning handle behind retaining strap.

CONVEYOR STROKE LINKAGE [7-5]. Refer to tag near linkage for choice of connections. Smaller stroke will inject product more times, and result in higher injection percentages.

## OPERATING INSTRUCTIONS



**Read instructions and review safety information (pages 5 through 11) before operating machine.**

1. Refer to “Installation” (page 21) to prepare machine for operation. Refer to “Machine Controls” (page 29) for description of controls.
2. Make sure all guards, covers, and safety devices are properly installed and in good working order (see page 25 for Daily Safety Circuit Test).
3. Keep immediate area of machine uncluttered. Avoid slippery conditions. Inspect for any damaged or missing parts. Immediately report any problem to supervisor.
4. Make sure filter unit is filled with fluid, all filters are in place, and provision has been made for replenish fluid supply.
5. Provide for adequate drainage.
6. Be sure to bleed fluid system until all air bubbles are removed. Injection rates will not be stable if air is in fluid system. Air bubbles may return if fluid system has a leak.
7. Filter screens may require cleaning during operation. To do this, remove only one pair of screens at a time, starting with pair nearest rotary filter. Clean and replace one pair before removing the next.



8. In addition to operator controls, successful operation is also affected by the following variables:
  - a. Temperature. Colder product may absorb less fluid.
  - b. Physical Characteristics. Meat, fish and poultry each have distinct physical characteristics (fat content, moisture content, tissue structure, etc.) that will respond to injection differently. Different injection pressures may be required to achieve a specific injection rate.
  - c. Trimming and Cutting. Product from different suppliers, or product cut by different individuals can vary in physical characteristics.
  - d. Air Pressure. Air pressure settings may not be identical from day to day. Supply pressure may vary during operation, causing momentary fluctuations.
  - e. Machine Condition. Normal wear will cause slight changes from day to day, especially in pump efficiency. Such changes may not be noticeable at first, but may suddenly become apparent after change accumulates. Routine adjustment and preventive maintenance will prolong machine life.

























**Do not leave machine energized while unattended.**














## READ & UNDERSTAND SAFETY INSTRUCTIONS IN THE MANUAL BEFORE USING THIS MACHINE.

### SAFE OPERATION – MODEL 1450

STEPS	INFORMATION	SAFETY / HEALTH
1. Training. 	Only qualified and trained personnel may operate. Read & understand safety & operating instructions in the manual. Repeat training periodically.	Keep all other people away from the machine. Needles are sharp. Keep hands and clothing away from moving parts.
2. Assemble machine. 	Assemble clean pump. Fluid filters in tank. Variable stroke as desired. Side panels installed. Hood and inlet guard closed. Drain tray in place. Filter unit positioned to catch run-off fluid. Daily lubrication.	Sanitize pump parts before assembly (see step 7). Edible lubricants only in food zone.
3. Connect utilities. 	Air (100psi)(700kPa). Electrical (see name plate for volts and amps). Fluid supply (maximum 75psi)(520kPa); fill filter unit; dissolve solution completely; <b>never run pump without fluid.</b>	Electrical connections by qualified electrician.
4. Set air pressures. 	Fluid (higher=more injection).  Stripper (higher=more force).  Assist (40psi)(275kPa).  Filter (higher=faster).	Injection limits may apply.
5. Bleed fluid system. 	Run pump (see step 8) and open bleed valve. Lock valve closed when all air bubbles disappear.	Provide for drainage. Floors must not be slippery.
6. Provide exit equipment to catch product. 	Variable stroke linkage determines output speed.	
7. Sanitize. 	Sanitize product zone immediately before beginning operation. Follow chemical label directions.	Use only chemicals approved for use with food. Needles are sharp. Edible lubricants only in food zone.
8. Run drive & pump. 	<b>Main disconnect switch:</b> 1=on. <b>Control switch:</b> In=off; out=on. <b>Drive start switch:</b> Push to start drive. <b>Pump start switch:</b> Push to start pump.	    Do not leave machine energized while unattended. Know how to stop before starting: Push control switch knob in, or turn disconnect switch off (0=off). Do Daily Safety Circuit Test—see manual. Keep hands and clothing clear of moving parts.
9. Lay product on infeed conveyor. 	Do not overlap product. Allow conveyor to carry product to needles.	Keep hands and clothing clear of moving parts.
10. Stop. 	<b>Stop drive:</b> Push drive stop button.  <b>Stop pump:</b> Push pump stop button.  <b>Stop all control:</b> Push control switch knob.  <b>All power off:</b> Turn main disconnect switch off (0=off). 	Clean machine soon after stopping operation. To prevent accidental start, lock out main disconnect switch. 

## READ & UNDERSTAND SAFETY INSTRUCTIONS IN THE MANUAL BEFORE USING THIS MACHINE.

### CLEANING – MODEL 1450

STEPS	INFORMATION	SAFETY / HEALTH
<p>1. Training.</p> 	<p>Only qualified and trained personnel may clean. Read &amp; understand safety &amp; operating instructions in the manual. Repeat training periodically. Clean soon after operation; sanitize just before restarting.</p>	<p>Keep all other people away from the machine. Needles are sharp. Keep hands and clothing away from moving parts. Clean machine soon after operation; sanitize just before restarting.</p>
<p>2. Lock out electrical.</p> 	<p>Lock main disconnect in off position (0=off).</p>	<p>Prevent unexpected start of machine. Prevent electrical shock.</p>
<p>3. Clean fluid system internally.</p> 	<p>Clean filters separately. Drain, rinse &amp; refill tank with approved internal cleaning agent (85°F)(30°C); solution must be completely dissolved. Reinstall last filter. At normal pressure settings run pump with bleed valve open 3 minutes. Close bleed valve, lower fluid pressure setting, run pump 1 minute. Repeat with clean rinse water. <b>Never run pump without fluid.</b></p>	<p>Do not run drive. Never run pump without fluid. Rinse water=drinkable.</p>
<p>4. Clean needles &amp; stripper.</p> 	<p>Low pressure spray (60psi)(400kPa). Large particles by hand. Retract needles if necessary (see manual). Refer to manual for unclogging needles.</p>	<p>Disassemble manifold to clean screen and needles periodically. Dispose of waste properly.</p>
<p>5. Remove loose parts.</p> 	<p>Raise hood &amp; inlet guard. Remove drain tray.</p>	<p>Maintain good footing.</p>
<p>6. Remove loose waste material.</p> 	<p>Rinse with warm water (95°-120°F)(35°-50°C), or remove particles by hand.</p>	<p>Dispose of waste properly.</p>
<p>7. Clean exterior.</p> 	<p>Use alkaline cleaner approved for food equipment. Scrub, soak or low pressure spray (60psi)(400kPa) until clean. Keep fluids out of seals and electrical.</p>	<p>Higher pressure will splash soil into other areas. Make sure to clean all areas.</p>
<p>8. Rinse.</p> 	<p>Low pressure (60psi)(400kPa). Warm water (95°-120°F)(35°-50°C).</p>	<p>Water quality=drinkable.</p>
<p>9. Reassemble. Keep machine clean.</p> 	<p>Store in clean room, or keep covered.</p>	<p>Control corrosion with film of edible oil.</p>
<p>10. Apply sanitizer.</p> 	<p>Immediately before operation sanitize entire food zone.</p>	<p>Use chemical approved for use with food. Follow label directions. Dispose of runoff fluids properly. Needles are sharp.</p>
<p>11. Return to operation.</p> 	<p>Floor must not be slippery.</p>	<p>Reconnect electrical only after everything is ready.</p>

# SECTION 4 CLEANING


— Contents —

Remove Soil .....	39
Sanitize .....	45



**Read instructions and review safety information (pages 5 through 11) before cleaning machine.**

## Cleaning



## CLEANING THE MODEL 1450

Procedure steps 1 thru 9 (clean) should be done immediately after operation has stopped. Steps 10 thru 12 (sanitize) should be done immediately prior to resuming operation.

### 1. Make sure electrical circuit will not turn on:


- a. Lock out electrical supply to the machine. Do not assume power is off when control switch [8-8] knob is not illuminated – the light bulb is a consumable item and may be burned out.
- b. Make sure control switch is pushed in for “off” position.

### 2. Clean fluid system internally:

- a. Remove plugs [8-24] and drain tank [8-19].
- b. Remove filter screens [8-23]. Rinse clean.
- c. Rinse rotary drum clean, removing particles by hand if necessary.
- d. Rinse out tank with warm water (95° to 120° F.)(35° to 50° C.).
- e. Install plugs, and refill fluid tank with lukewarm (85° F.)(30° C.) cleaning agent suitable for internally cleaning the fluid system. Install filter screen pair.
- f. With fluid [8-9] and assist [8-11] pressures at normal settings, start pump [8-12] and open bleed valve [11-25]. Run at least three minutes to clean needles and manifold.
- g. Lower fluid pressure to zero and close bleed valve. Run pump for one minute to flush control valve and return hose.
- h. Stop pump [8-5], open bleed valve, drain tank. Remove, clean, and reinstall a clean filter screen pair.
- i. Fill tank with lukewarm clean rinse water. Repeat steps f thru g to rinse fluid system.

Note: If you encounter difficulty cleaning the rotary drum, call Stork Townsend for assistance, (515) 265-8181.

## Cleaning





**3. Clean needles and stripper:**

- a. Using low pressure spray (60 psi)(400 kPa), remove particles from exterior of needles and stripper [9-22] area.
- b. If particles remain lodged in needle [9-23] zone, set stripper pressure [9-10] to zero (assist cylinder pressure at normal setting). Raise head carriage [9-21] and position soft wood or rubber block (2.5 x 5 x 13.5 in) (7 x 13 x 35 cm) under needles (material must not damage needle points).
- c. Lower head carriage until block pushes needles up approximately 2-1/2 inches (7 cm). Set stripper pressure back to normal setting and raise head until needles are above stripper.
- d. Using low pressure spray (60 psi)(400 kPa), remove any remaining particles. Remove large particles by hand if necessary. Note: Needles will automatically extend to normal position when normal fluid pressure is reapplied.
- e. If needles are clogged, remove upper manifold housing [9-19], remove needles with pulling tool (p/n 10080), and clean with cleaning tool (p/n 11691). Note: With manifold open, clogged needles are recognizable by fluid standing in respective needle bores.


**4. Open machine for cleaning:**

- a. Raise hood [9-14] and inlet guard [9-15].
- b. Remove drain tray [9-4].
- c. Place disassembled parts in suitable wash area or container.

**5. Remove loose waste material:**

- a. Rinse machine and all disassembled parts with warm water (95° to 120° F.)(35° to 50° C.), or otherwise remove debris by hand. Give particular attention to conveyor belt.
- b. Dispose of waste material properly.

## Cleaning



**6. Apply cleaning agent:**

- a. Coat machine and all disassembled parts with alkaline cleaning agent approved for use on food processing machinery – follow chemical manufacturer's directions completely.
- b. Use care when cleaning around electrical components, or near seals so fluids do not penetrate those devices. Use care to prevent damage or removal of labels.
- c. Depending on chemical product being used, thorough cleaning will require one or more of the following processes – follow manufacturer's directions:
  1. Scrub with nylon brush.
  2. Use low pressure spray (60 psi)(400 kPa). Take special care to protect electrical components, seals, and labels when using pressure sprayers.
  3. Provide required soak time.

**7. Final rinse:**

- a. Thoroughly rinse the cleaning agent and all waste material off the machine, using low pressure warm water (60 psi at 95 to 120 °F.)(400 kPa at 35 to 50 °C.), and paying special attention to all surfaces and areas in, and directly above, the product zone.


**8. Reassemble machine:**

- a. Install drain tray [10-4].
- b. Check that hose connections are tight.
- c. Close hood [10-14] and inlet guard [10-15].

**9. Keep machine clean:**

- a. Allow machine to air dry in clean environment.

## Cleaning



**10. Apply sanitizer (do immediately before operation):**

- a. Apply sanitizer. Surfaces that cannot be removed and immersed in sanitizer must be coated with type of sanitizer capable of killing germs on contact. Follow manufacturer's recommendations completely. Test kits are available from chemical supplier to assure proper chemical concentrations.
- b. The following surfaces must be sanitized:
  1. All surfaces of the machine that might contact food product.
  2. All surfaces that the operator might contact.
  3. Any surrounding areas which fluids, product, or utensils might contact and then move into food-contact or operator-contact areas.

**11. Drain sanitizer:**

- a. Drain off sanitizer thoroughly.
- b. Dispose of runoff fluid properly.

**12. Return machine to operation:**

- a. Secure machine in operating position. Make sure surrounding floor is not slippery.
- b. Locate filter unit [11-1] beside Model 1450. Align to catch runoff fluid from injector. Connect fluid hoses. Install all required filter screens. Cover replenish compartment with lid [11-16]. Fill tank with premixed fluid.
- c. Machine is now ready to re-connect to electrical supply.



# SECTION 5 MAINTENANCE

## — Contents —

Preventive Maintenance . . . .	49	Conveyor Drive . . . . .	67
Lubrication		Conveyor . . . . .	73
Model 1450 . . . . .	50	Head Carriage . . . . .	77
USDA Standards . . . . .	52	Stripper . . . . .	79
Overhaul Guidelines . . . . .	54	Pump –	
Variable Stroke Linkage . . . .	57	Preventive Maintenance . . .	83
Conveyor Speeds . . . . .	57	Pump – Overhaul . . . . .	85
Control Valve . . . . .	59	Air System . . . . .	91
Stripper Stops . . . . .	61	Fluid System . . . . .	93
Fluid Hoses . . . . .	63	Electrical System . . . . .	94
Filter Screens . . . . .	65		






**Read instructions and review safety information (pages 5 through 11) before investigating problems or servicing machine.**



**Lock out electrical supply and disconnect air supply before performing any maintenance procedure. Re-connect these utilities only if maintenance procedure absolutely requires them.**

## Preventive Maintenance






## PREVENTIVE MAINTENANCE

The following is a list of checks to be made and when to make them.

PREVENTIVE MAINTENANCE	DAILY	MONTHLY	QUARTERLY
1. Clean & sanitize machine. Perform daily lubrication.	●	●	●
2. With stripper pressure [12-5] set at zero, check for free movement of stripper [12-9], cylinders, and valve linkage.	●	●	●
3. Check conveyor belt tension [12-6].	●	●	●
4. Check conveyor brake [12-7] adjustment.	●	●	●
5. Check needles [12-10] for bent, dull, or clogged condition.	●	●	●
6. Inspect machine for damaged or missing parts or safety devices.	●	●	●
7. Inspect fluid pump seals [12-4] and O-rings.	●	●	●
8. Check operation of all electrical components – see Daily Safety Circuit Test (page 25).	●	●	●
9. Perform monthly lubrication.		●	●
10. Check overall condition of machine, especially guards, covers, and safety devices.		●	●
11. Check condition and adjustment of drive belt [12-2] and chain [12-3].		●	●
12. Inspect bearings, seals and grease lines.		●	●
13. Inspect fluid hoses, air tubing, and fittings.		●	●
14. Disassemble and inspect assist cylinders [12-11]. Lubricate.		●	●
15. Replace fluid pump seals. Inspect pump gears [12-1].		●	●
16. Change grease in conveyor clutch [12-8].		●	●
17. Perform quarterly lubrication.			●
18. Check drive components: motor, bearings, pulleys, belts, keys and keyways, keepers and setscrews.			●
19. Check fluid pump bearing housing assembly for smooth operation.			●
20. Inspect self-lubricating bearings and all moving parts.			●

## Lubrication Instructions



### Lubrication Supplies

<u>Code</u>	<u>P/N</u>	<u>Description</u>
EG	12080	Edible Grease (13 ounce tube)
RCL	none	Roller chain lubricant (commercially available)
O-10	03094	10W Food Grade Oil (1 quart)
WPG	11861	Waterproof Grease (14 ounce tube)
GO	10603	Gear Oil – EP90 (gallon)
–	12450	Grease gun
–	13722	Flexible Hose (12 inch)

## LUBRICATION INSTRUCTIONS

Lubrication is essential for maximum service from the machine. Lubricants that could come in contact with food must be approved by USDA, or comparable government regulatory agency, for use in food zone.

Remove any excess lubricant from the exterior of the equipment.

POINT OF LUBRICATION	LUBRICANT	DAILY	MONTHLY	QUARTERLY
1. Head carriage pivots. Two fittings.	EG	●	●	●
2. Stripper cylinders. Two fittings.	EG	●	●	●
3. Head carriage tie rod (upper end). Two fittings.	EG	●	●	●
4. Drive chain tensioner. One fitting.	WPG	●	●	●
5. Head carriage tie rod (lower end). Two fittings.	WPG	●	●	●
6. Crankshaft. Two fittings.	WPG	●	●	●
7. Countershaft. Two fittings.	WPG	●	●	●
8. Fluid pump bearing housing assembly. Two fittings.	WPG	●	●	●
9. Air motor filter unit. Adjust automatic air line lubricator to one drop/50–75 cfm (23–35 L/sec)	O-10	●	●	●
10. Variable stroke link pivot. One fitting.	EG	●	●	●
11. Coat drive chain.	RCL		●	●
12. Replace fluid pump seals.			●	●
13. Piston in fluid control valve. Clean and apply fresh grease to piston seals and piston bore.	EG		●	●
14. Filter unit spur gears. Coat teeth.	EG		●	●
15. Conveyor drive clutch. Pump full with fresh grease.	EG		●	●
16. Assist cylinders. Disassemble, clean, saturate oiler pads.	O-10			●
17. Threads on feet and jackscrews; caster swivels; wheel axles.	O-10 or EG			●
18. Filter unit gear box. Fill both reservoirs.	GO			●

## LUBRICATION – USDA CLASSIFICATIONS

All lubricants used on food processing machines or in a food processing facility must be approved by USDA for this use. USDA has two classifications for lubricants that are approved for food processing applications.

### **H1 Lubricants as defined by USDA regulation**

“These compounds may be used as a lubricant with incidental food contact for use in official establishments operating under the [USA] Federal meat and poultry products inspection program. Such compounds may be used on food processing equipment as a protective anti-rust film, as a release agent on gaskets or seals of tank closures, and as a lubricant for machine parts and equipment in locations in which there is potential exposure of the lubricated part to food. The amount used should be the minimum required to accomplish the desired technical effect on the equipment. If used as an anti-rust film the compounds must be removed from the equipment surface by washing or wiping, as required to leave the surface effectively free of any substance which could be transferred to food being processed.”

### **H2 Lubricants as defined by USDA regulation**

“These compounds may be used as a lubricant, release agent, or anti-rust film on equipment and machine parts or in closed system (e.g., hydraulic systems) in locations in which there is no possibility of the lubricant or lubricated part contacting edible products.”

### **Repair Parts and Procedures Using Lubricants**

All replacement parts and all repair procedures must utilize only approved lubricants which are appropriate for their specific location. For example, if a permanently lubricated bearing is used in the food zone, its internal lubricant must be classified H1. Likewise, if a lubricant is used to assemble close fitting parts in the food zone, this lubricant must be classified H1.

### Lubricants Available From Stork Townsend

If a lubricant is not classified either H1 or H2 by USDA it must not be used anywhere in a food processing facility, or in or on a food processing machine.

All lubricants offered by Stork Townsend are USDA approved. Make sure, however, that they are used properly. Specifically, if there is a possibility that the lubricant could contact the food product or food zone, then a lubricant classified H1 must be used; lubricants classified H2 must only be used where there is no possibility of contact of the lubricant with the food product or the food zone.

See page 50 for specific instructions for the Model 1450.

### Lubrication Supplies

<u>PART</u> <u>NUMBER</u>	<u>USDA</u> <u>CLASS</u>	<u>DESCRIPTION</u>
03094 ...	H1 . . . . .	Oil, SAE10/ISO32, non-detergent (quart)
25424 ...	H1 . . . . .	Gear Oil, SAE90/ISO220
12080 ...	H1 . . . . .	Grease, NLGI-1 (13 ounce tube)
15127 ...	H2 . . . . .	Lenze Oil (gallon)
10603 ...	H2 . . . . .	Gear Oil, SAE90/ISO220 (gallon)
23744 ...	H2 . . . . .	Gear Oil, SAE140/ISO440 (gallon)
11861 ...	H2 . . . . .	Grease, high temp, NLGI-2 (14 ounce tube)
16027 ...	H2 . . . . .	Grease, NLGI-2 (14 ounce tube)
12450 ...	— . . . . .	Grease gun (with standard small fitting)
13722 ...	— . . . . .	Flexible Hose (12 inch)(30,5 cm)

# OVERHAUL GUIDELINES

## General Instructions

### ORGANIZE THE WORK

Work in an organized manner, keeping the work area clean. Lay parts out in a disassembly sequence. When fasteners are removed, reinstall them in their respective holes to keep track of where they go.

### REPLACE SEALS & BEARINGS

When seals are taken apart, replace them with new seals. Also, because of the time required for most disassembly, it is usually economical to replace bearings with new bearings when disassembly occurs. When installing close fitting parts, lubricate their mating surfaces to prevent damage during installation. Use only USDA type H1 lubricant if the lubricant could come in contact with the food product or the food zone – refer to page 50 for full explanation.

### WORN OR DAMAGED PARTS

During disassembly, any parts that appear worn or damaged should be replaced to prevent repeated disassembly at a later time.

### SELF-LOCKING FASTENERS

Lock nuts and lock washers should be replaced once they have been removed or loosened – plastic and stainless materials of such fasteners do not retain locking properties for more than one installation.

### SANITATION

Because this machine handles food materials, organic matter may be present on the equipment and could be a source of infection. Have the machine cleaned before servicing it. Wear appropriate protective gear. If you get cut, obtain medical treatment immediately. Preserve the sanitary design of the machine.

### PRESERVE THE ORIGINAL DESIGN

Repair parts must be Stork Townsend approved spare parts. To preserve maximum operating safety, never alter the original design of the machine. Use the machine only for the purpose for which it was designed and intended. Do not modify the machine in any way without Stork Townsend approval.

### LUBRICANTS

All lubricants used in a food processing facility must be approved by USDA for this use – refer to page 50 for full explanation.

# OVERHAUL INSTRUCTIONS

## Safety Precautions

### MACHINE DESIGN

Do not alter the design of the machine – this will compromise the intended safety and hygiene features of the machine. Use only Stork Townsend approved replacement parts.

### GUARDS & SAFETY EQUIPMENT

Always install all guards and safety devices on the machine, and verify their correct operation before running the machine.

### SHARP EDGES & MOVING PARTS

Take extreme care when working around sharp equipment, or any moving parts. Prevent clothing from getting caught in moving parts. Do not wear jewelry when working on machinery.

### CONDITION OF MACHINE & WORKING AREA

Remove lubricants, fat, or liquids from the equipment being repaired – slippery surfaces are more difficult to work on. Keep the working area clean and clear of obstacles or loose parts. The working area should be level, with good footing.

Use the right tool – accidents increase when the wrong tools are used.

### ELECTRICAL

High voltage is connected to this machine. Never contact this voltage – electrical shocks can be fatal. To guarantee the machine will not run unexpectedly during maintenance, and to prevent electrical shock, always lock out the electrical supply to the machine, using a lockable switch separate from the machine. The person doing the maintenance work must control this lock.

### FOR ASSISTANCE

For assistance with any application or service questions, contact Stork Townsend:

Stork Townsend Inc.  
2425 Hubbell Avenue,  
Des Moines, IA 50317 USA

N. America: 800 247-8609  
Intl. 515 265-8181  
Fax: 515 263-3355




[www.townsendeng.com](http://www.townsendeng.com)

Stork Townsend B.V.  
Industrielaan 63 - 5349 AE, Oss, The Netherlands  
P.O. Box 292 - 5340 AG, Oss, The Netherlands

Telephone: +31 (0)412 669 911  
Fax: +31 (0)412 669 250

[www.townsend.nl](http://www.townsend.nl)

## Variable Stroke Linkage





## VARIABLE STROKE LINKAGE




### Adjustment

Linkage driving the conveyor belt can be connected in several ways to change the amount of movement of the belt for each cycle of the needles. Using a shorter stroke to drive the belt slows down the belt speed, and will increase the overlap of the needle pattern, increasing the resulting injecting percentage.

### Conveyor Speeds

<b>Conveyor Speeds (with standard drive pulley)</b>		
<b>Linkage</b>	<b>inches (cm)/stroke</b>	<b>feet (meter)/minute</b>
1/4	0.5 (1,3)	5.5 (1,68)
1/2	1.0 (2,5)	11.3 (3,43)
3/4	1.5 (3,8)	16.5 (5,03)
FULL	2.0 (5,1)	22.0 (6,71)
1-1/4	2.5 (6,4)	26.0 (7,92)
1-1/2	3.0 (7,6)	32.0 (9,75)
1-3/4	3.5 (8,9)	37.0 (11,28)
2x	4.0 (10,2)	44.0 (13,41)

## Control Valve



## CONTROL VALVE

### Adjustment

Adjust the control valve [15-4] only after the head carriage [15-5], needle [15-7] clearance, stripper [15-6], and stripper stops [15-8] are properly adjusted, with the stripper cylinder regulator [15-1] set at normal operating pressure. Check the stripper cylinder bushings and cushions. Check bushings in the linkage connecting the valve to the stripper. Replace worn parts before adjusting the valve.



Two valves are available. A small capacity valve is used with RB10 and RB15 pumps [15-10]. A large capacity valve is used with the RB30 pump. Because the opening in the valve body [15-11] of these two valves is different, adjustment procedure is slightly different with each valve.

1. Remove fluid manifold [15-2] and cross tube [15-3].
2. Raise head carriage to highest point and block up using wood block between framework.
3. Check position of white plastic insert [15-9] in valve – insert is visible through outlet port [15-13] of valve. **For small capacity valve**, the bleed hole [15-14] should be half-covered along upper edge of slotted opening. **For large capacity valve**, the lower edge [15-15] of insert should just cover the lower edge of slotted opening.
4. To change adjustment, loosen clamp bolts and rotate plastic insert until desired position is obtained (see 3 above). Retighten clamp bolts.

After this initial setup is done, use the following procedure to keep the valve in top operating condition as parts wear.

1. Brace the head carriage up in a middle position.
2. Turn stripper pressure to zero.
3. Loosen clamp screws on valve insert.
4. Using a large flat blade screwdriver, turn valve insert counterclockwise until a steady flow of fluid comes from the needles.
5. Slowly turn valve insert clockwise until the steady flow becomes a constant dripping similar to gentle rainfall.
6. Retighten clamp screws.
7. Confirm that this setup procedure has been done correctly by seeing that a steady, strong stream of fluid will spray from the needles when you raise the stripper plate manually.

## Stripper Stops




## STRIPPER STOPS

### Adjustment

If product could be damaged by pressure of stripper [16-4] as needles [16-5] pierce product, install optional stripper stops [16-6] to stop downward movement of stripper before product is crushed. Vertical and horizontal positions are adjustable. Cushions [16-7] should be centered in path of stripper cylinder [16-1]. Left and right stops should be level with each other.

1. Loosen jam nut guard [16-11] on bottom side of large rectangular washers [16-10].
2. If height adjustment is to be changed, thread upper lock nut [16-9] up or down along push rod guide [16-8]. The two stripper stops must contact stripper cylinders simultaneously.
3. If side-to-side position is to be changed, slide large rectangular washers until desired position is reached.

## Fluid Hoses





## FLUID HOSES

Loose fittings, or cracks in hoses will allow fluid to leak or air to be pulled into the fluid system. Use only hoses supplied by Stork Townsend, and which are approved for application on the Model 1450. Any other hoses may not be approved for use with food handling applications, or for the types of fluids being pumped by the Model 1450.

Choice of two pumps, with differing output capacities, changes sizes of other fluid system components, including hoses.

## Filter Screens





## FILTER SCREENS

The filter screens remove particles from the fluid. Three pairs of screens filter the runoff fluid so that it can be reused. A fourth pair of screens filter the fresh replenish fluid, combined with the runoff fluid.

Filter screens are available in three choices – fine, medium, and coarse. Select the screens according to the characteristics of the fluid and the product that is being run, in order to maximize effective filtration, and so that filtered particles are spread across the set of screens such that the machine can run the longest interval between cleanups.

Clean the screens as needed – the fluid must never flow around a clogged screen. Clean the screens at least once each shift. The screens must be clean before the fluid system can be cleaned internally (see page 39).

### Cleaning While Operating



The screens may be cleaned while production continues if done in the following manner.

1. When screen blockage is first noticed, remove the first screen of the first pair. Rinse and replace. Remove the second screen of the first pair. Rinse and replace. Continue normal operation.
2. When screen blockage is again noticed, repeat the procedure with the first pair of screens, and then do the same with the second pair of screens. Continue normal operation.
3. When screen blockage occurs again, repeat the procedure with the first pair of screens, and then with the second pair of screens, and then with the third pair of screens. Continue normal operation.
4. When screen blockage occurs a fourth time, shut off the supply of replenish fluid, and continue operating until the fluid level almost reaches the suction port connecting to the pump.
5. Stop the machine. Drain all remaining fluid from the tank. Remove all screens, including the fourth pair of screens. Clean the entire tank, inside and out. Clean all pairs of screens, and replace them in the same positions that they were originally in. Refill the tank and resume normal operation.

Note: Never remove the fourth pair of screens unless the entire tank is going to be cleaned as described in step 5 above. Removal of this pair of screens will allow unfiltered fluid to clog the needles.

Caution: Never install any other filter in the suction line to the pump. This will damage the pump.

## Conveyor Drive



## CONVEYOR DRIVE

### Drive Belt Adjustment

1. Lock out electrical supply.
2. Inspect drive belt [19-6] and check for proper pulley alignment.
3. Loosen motor mount bolts [19-9], and jam nuts [19-10] on jackscrews [19-11].
4. Turn jackscrews until belt is tensioned. Tighten motor mount bolts and jam nuts on jackscrews to retain position.



### Drive Belt Replacement

1. Lock out electrical supply.
2. Remove bolts in countershaft [19-7] bearing housing [19-5] nearest drive belt [19-6].
3. Disconnect grease line [19-4] to bearing.
4. Loosen drive tensioner [19-3] to allow counter shaft to move. Insert new belt between bearing and cabinet.
5. Reassemble machine. Adjust drive belt and drive chain [19-1].

### Drive Chain

1. Lock out electrical supply.
2. Inspect drive chain [19-1] and idler sprocket [19-2] and check for proper alignment.
3. Loosen bolts [19-12] holding tensioner.
4. Rotate tensioner to adjust drive chain. Chain must have no slack but must not be highly tensioned.
5. Retighten bolts to retain position of tensioner.
6. Lubricate drive chain with commercially available roller chain lubricant.
7. To replace chain, separate chain at connecting link.

## Conveyor Drive




## CONVEYOR DRIVE

### Drive Motor Replacement

1. Lock out electrical supply.
2. Remove end and bottom panels at rear of machine.
3. Disconnect wiring to motor [20-3].
4. Loosen jackscrews [20-6] and remove motor mounting bolts [20-5].
5. Install new motor, reusing watertight connector [20-4] and pulley [20-2].
6. Install and adjust drive belt[20-1].
7. Check that electrical requirements of new motor are same as old. If amperage is different, it is necessary to change setting of motor protection heater (located inside control panel) to match new rating. If old heater can not be adjusted to match new requirement, replace with proper heater.
8. Check for proper motor rotation. Motor must run counterclockwise when viewed from shaft end. To reverse direction, switch any two leads of power supply to motor.

## Conveyor Drive



## CONVEYOR DRIVE


### Countershaft Replacement

1. Lock out electrical supply.
2. Disconnect grease lines [21-12][21-20] to countershaft bearings [21-18][21-13].
3. Separate drive chain [21-8] at connecting link.
4. Loosen setscrews [21-14] in bearing inner races.
5. Remove bolts [21-19] holding bearing housings and remove countershaft [21-17] assembly.
6. Reassemble and align sprockets [21-11][21-9][21-4] and pulley [21-16].
7. Install drive chain and adjust chain and drive belt [21-15].
8. Lubricate drive chain.

### Crankshaft Replacement

1. Lock out electrical supply.
2. Set head carriage in lowest position.
3. Block head carriage up securely. Do not block under stripper.
4. Remove left and right tie rod/crankarm [21-7][21-1] assemblies.
5. Remove rear access cover and relax tensioner [21-10] on drive chain [21-8].
6. Loosen sprocket [21-4] on crankshaft [21-2].
7. Loosen clamp bolts [21-5] in inner bearing sleeves [21-6].
8. Slide crankshaft [21-2] out while supporting sprocket [21-4].
9. Install new crankshaft, reusing old key [21-3] for sprocket.

## Conveyor





## CONVEYOR

### Conveyor Belt

Adjust conveyor belt [22-8] tension with hex adjustment screws [22-1] in idler shaft [22-2]. Tighten belt to take out slack. Do not overtighten.

To replace conveyor belt, relax tension and separate belt by removing a connecting rod [22-7]. Install new belt using new connecting rod. (Note: Orient metal belts [22-8] so that drive sprocket teeth [22-9] drive against connecting rods [22-7]. Orient plastic belt with milled-off inside surface near to clutch.)


To install connecting rod on metal belts, thread nut [22-6] onto rod then cut off excess thread while deforming thread to secure nut in place. On plastic belts [22-11] retain connecting rods [22-10] by melting end of rod.

### Conveyor Brake

Adjust conveyor brake with hex head screws [22-3], one in each brake shoe [22-4]. Tighten brake just enough to prevent conveyor belt from coasting at end of clutch travel. Do not overtighten.

When brake wears and is no longer effective, remove approximately 1/16 inch (1,5 mm) material from mating face of each shoe. Remount brake on conveyor drive shaft [22-12] and adjust set collar [22-5] to take out shaft end play. Set collar must not press too heavily against side of brake.

## Conveyor




# CONVEYOR

## Drive Clutch

Proper lubrication is essential for maximum clutch life. Fill clutch [23-7] with fresh grease monthly. Do not, however, disassemble clutch. Clutch can not be repaired or rebuilt in the field.

1. Lock out electrical supply.
2. Relax conveyor belt [23-5] tension. Remove one connecting rod [23-2] to break apart conveyor belt. Unwrap belt from drive shaft [23-9] and sprockets [23-4]. Disconnect clutch drive linkage [23-12]. Unbolt end housings [23-11], then remove conveyor drive shaft assembly.
3. Loosen clutch housing [23-6]: To do this on plastic belt [23-15] machines, slide sprocket [23-13] from housing, then drive out pin [23-14]. On metal belt [23-5] machines, pin [23-3] must be removed before sprocket [23-4] can be separated.
4. Remove housing cover [23-10] and slide housing [23-6] toward center of shaft.
5. If clutch needs to be removed, loosen setscrew in clutch hub and slide clutch assembly toward center of shaft until woodruff key [23-8] can be removed. Slide clutch off shaft.
6. Remove one of the three plugs [23-1]. Replace it with a standard grease fitting.
7. Pump specified type of grease (USDA-approved type H1, Sork Townsend part number 12080 – see page 50) until new grease flows freely from around the shields, purging all old grease. Reinstall original plug and tighten securely. Note: Do not mix different brands of grease; do not substitute oil for grease.
8. Coat outside of clutch with edible grease or edible oil to facilitate assembly.
9. Carefully align parts and reassemble conveyor drive shaft.
10. Install conveyor drive shaft and conveyor belt and reconnect drive linkage. Tension conveyor belt.

## Head Carriage



## HEAD CARRIAGE



### Head Carriage Adjustment

1. Lock out electrical supply.
2. Loosen jam nuts [24-1] on head carriage pivot shafts.
3. Rotate eccentric pivot shafts [24-2] to center head carriage over conveyor belt. Retighten jam nuts securely.
4. With head carriage in lowest position, loosen jam nuts [24-4][24-8] on each end of head carriage tie rods [24-7]. Tie rods have opposite hand threads on each end.
5. Turn tie rods to obtain 1/32 inch (0,8 mm) clearance between needle [24-17] tips and conveyor belt [24-18]. Adjust rods evenly to prevent binding.
6. Tighten jam nuts securely.
7. Adjust stripper [24-5] – see page 79.

### Assist Cylinders

1. Lock out electrical supply.
2. With head carriage in lowest position, set assist cylinder pressure to zero.
3. Disconnect air lines [24-6] and remove assist cylinders [24-3].
4. Remove piston rod [24-13] and clean and inspect cylinder [24-9] bore. Hone cylinder to remove scratches.
5. Clean and inspect pistons [24-11][24-15] and felt oiler pads [24-12][24-14].
6. Install new seals [24-10][24-16] as shown. Use only original equipment seals. Use of other seals will cause heat build-up and will damage cylinders and drive train of machine.
7. Saturate oiler pads with 10W edible oil (Stork Townsend part number 03094) and reassemble. Reset assist cylinder pressure to 40 psi (275 kPa) before running.

## Stripper





# STRIPPER

## Stripper Adjustment

1. Lock out electrical supply.
2. Check head carriage adjustment and needle clearance.
3. Set normal stripper pressure – approximately 50 psi (345 kPa).
4. Loosen mounting bolts [25-3] of stripper cylinders [25-2]. Move cylinders to center stripper [25-7] on needles [25-4].
5. Tighten mounting bolts securely. Stripper must have slight amount of end play with cylinders fully extended.
6. Loosen jam nuts [25-6] under each stripper yoke [25-5]. Turn push-rods [25-8] to bring bottom of stripper plate [25-10] to within 1/64 inch (0,4 mm) of conveyor belt. Stripper plate may touch conveyor belt lightly.
7. Tighten jam nuts securely. Recheck adjustment.
8. Lubricate cylinders [25-9] – see Lubrication Instructions (page 50).
9. Check for free movement – see Preventive Maintenance (page 49).
10. Check control valve [25-1] adjustment (see page 59).

## Stripper







# STRIPPER

## Stripper Cylinders

1. Lock out electrical supply.
2. Set stripper pressure to zero and disconnect air lines [26-1].
3. Remove grease fitting [26-18] and jam nut [26-6].
4. Unscrew pushrod [26-14] from stripper yoke [26-5], remove mounting bolts [26-4], and remove cylinders [26-3] from machine.
5. Disassemble cover [26-8] from guide housing [26-15].
6. Install new rod seals [26-16][26-20] and bushings [26-17] [26-19] in guide housings [26-15].
7. Install new piston cup [26-12], taking care to align bleed holes in piston cup and washer [26-11] with hole in pushrod piston.
8. Install new cushion [26-13]. Groove in cushion must face piston.
9. Reassemble cylinders using new O-ring [26-9] in cover [26-8]. Install cylinders in machine. Adjust stripper [26-7] as described above.
10. Lubricate cylinders [26-18] – see Lubrication Instructions (page 50).
11. Check for free movement – see Preventive Maintenance (page 49).
12. Check control valve [26-2] adjustment (see page 59).

## Pump – Preventive Maintenance



## PUMP – PREVENTIVE MAINTENANCE

Normal wear will cause loss in pump efficiency. As pump efficiency decreases, compensate by increasing fluid system pressure to maintain injection percentage. When pump efficiency is too low for satisfactory operation, pump gears must be replaced. Seals should be replaced monthly, or whenever leakage is suspected, whichever comes first. Check weep hole [27-14] daily for fluid leakage.


### Preventive Maintenance

Lubricate daily with recommended waterproof grease (Stork Townsend p/n 11861). Refer to Lubrication Instructions (page 50).

### Replacing Pumps Seals

1. Lock out electrical supply.
2. Remove pump cover [27-1], gear housing [27-3], gears [27-5], keys [27-13], and seal plate [27-6] assembly.
3. Remove seal retainer [27-8] from seal plate to replace flanged lip seal [27-7].
4. Remove two glands [27-10] to replace their O-rings [27-11] and lip seals [27-12].
5. Clean surface of seal sleeves [27-9] with non-abrasive cleaner.
6. Install seal gland assemblies.
7. Install seal plate assembly.
8. Install gear housing with new O-rings [27-2][27-4].
9. Install keys, gears, and cover.

## Pump Overhaul – Wear Sleeves




## PUMP OVERHAUL – WEAR SLEEVES

### Wear Sleeve Replacement

1. Lock out electrical supply.
2. Remove cover [28-1], gear housing [28-2], and gears [28-3].
3. Check shafts [28-10] for play – if bearings are loose, rebuild bearing housing assembly – see page 87.
4. Remove drive pin [28-12], old sleeve [28-8], and O-rings [28-9] from each shaft.
5. Clean shafts and remove any salt accumulations.
6. Coat shafts with edible grease, then install new O-rings [28-9].
7. Apply edible grease to inside of new sleeves and carefully slide sleeves onto each shaft, taking care not to damage O-rings.
8. Line up drive pin holes [28-11] in each sleeve and shaft.
9. Carefully install new drive pin [28-12] from outside each sleeve into the shaft. Do not strike new sleeves with hammer or drift.
10. Cover outside of each sleeve with thin coat of edible grease.
11. Replace lip seals [28-5]. Make sure there are no scratches on seal plate [28-4] bores.
12. Replace seal retainer [28-6]. Do not over-tighten screws [28-7].
13. Reassemble pump.

## Pump Overhaul – Bearing Housing





## PUMP OVERHAUL – BEARING HOUSING

### Bearing Housing Assembly Overhaul

1. Lock out electrical supply.
2. Remove access panel above pump. Disconnect grease lines [29-27] from pump.
3. Remove pump from cabinet.
4. Remove pump cover [29-1], gear housing [29-3], gears [29-4], keys [29-22], and seal plate [29-5] assembly. If RB30 pump, replace bushings [29-2] in cover.
5. Remove shaft coupling [29-28]. Remove rear seal plate [29-11] and sleeve [29-10].
6. Remove glands [29-26] and their O-rings [29-25] and lip seals [29-24].
7. Slide shaft [29-23] assemblies from housing [29-14].
8. Drive pins [29-21] out to remove front seal sleeves [29-7] and O-rings [29-8] under sleeves.
9. Remove bearing lock nuts [29-16], and press large bearings [29-17] off (1 each shaft).
10. Remove outer [29-18] and inner [29-20] spacers, and roller bearings [29-19] (2 each shaft).
11. Remove rear lip seal [29-12], plug [29-9], and O-ring [29-13].
12. Remove grease relief ports [29-15].
13. Replace all bearings and seals. Clean and inspect remaining parts for wear or damage.
14. Pack bearings with waterproof grease (Stork Townsend p/n 11861) before installing on shafts. Tighten bearing lock nuts [29-16] securely.
15. Reassemble and install pump. Note: Alignment mark (V) [29-6] on seal plate must be adjacent to mark on bearing housing.
16. Lubricate according to Lubrication Instructions on page 50.

## Pump Motor





## PUMP MOTOR


### Pump Motor Replacement

1. Lock out electrical supply.
2. Remove air filter panel [30-4] and access panel [30-2] above pump [30-3].
3. Remove end and bottom screws [30-6][30-9] attaching pump drawer [30-7].
4. Remove pump drawer.
5. Install new electrical motor [30-5], aligning with pump [30-8].


Note: Connect motor electrical supply so motor runs counterclockwise when viewed from shaft end. Never run pump dry. If new motor has different amperage rating, adjust motor protection overload relay (located inside control panel [30-1]) to 125% of the new full-load rating. If new requirement exceeds range of existing overload relay, replace with correct overload relay .

6. Reassemble machine. Tighten all bolts securely.




## Air System




## Air System



## Fluid System



## Fluid System



## **ELECTRICAL SYSTEM**

Electrical diagrams for the 1450 are in the holder at the rear of the manual.

# SECTION 6 TROUBLESHOOTING

## — Contents —

Check These First .....	97
Problems & Causes .....	98



**Read instructions and review safety information (pages 5 through 11) before investigating problems or servicing machine.**



**Lock out electrical supply and disconnect air supply before performing any maintenance procedure. Re-connect these utilities only if maintenance procedure absolutely requires them.**





## TROUBLESHOOTING THE MODEL 1450

Several variables affect machine performance. Variations in these may appear to be machine malfunction, but must be fully evaluated before adjusting or repairing machine.

### **Temperature**

Colder product may absorb less fluid.

### **Physical Characteristics**

Meat, fish and poultry each have distinct physical characteristics (fat content, moisture content, tissue structure, etc.) that will respond to injection differently. Different injection pressures may be required to achieve a specific injection rate.

### **Trimming and Cutting**

Product from different suppliers, or cut by different individuals can vary in physical characteristics.

### **Operating Procedures and Adjustments**

Air pressure settings may not be identical from day to day. Supply pressure may vary during operation, causing momentary fluctuations.

### **Machine Condition**

Normal wear will cause slight changes from day to day, especially in pump efficiency. Such changes may not be noticeable at first, but may suddenly become apparent after change accumulates. Routine adjustments and preventive maintenance will prolong machine life.

## Problems and Causes

### 1. Machine (or pump) will not start, or stops during operation:

- a. Electrical supply interrupted.
- b. Interlocked guard or cover has moved – once cover has moved, start switch must be pressed again.
- c. Magnet not securely installed on interlocked guard or cover.
- d. Interlock switch is not securely installed, or is not correctly positioned to receive signal from magnet mounted to guard or cover.
- e. Motor overload relay tripped – correct overload condition, then reset relay.
- f. Blown fuse – correct overload condition, then replace fuse.
- g. Control switch contacts stuck (contacts must release in order to reset and restart the control circuit).

### 2. Low injection percentage:

- a. Loss of replenish fluid supply – tank should be over half full.
- b. Plugged needles.
- c. Air in fluid system. To verify, operate with bleed valve open – if percentage increases, problem is probably air. If unchanged, problem is probably mechanical – see other causes under problem 2.
- d. Worn needle seals.
- e. Worn or damaged seals on control valve piston.
- f. Incorrect adjustment of one or more of the following:
  - needle clearance;
  - stripper plate clearance;
  - control valve;
  - stripper stops.
- g. Worn or damaged valve linkage parts.
- h. Broken stripper plate frame.
- i. Damaged or worn fluid pump gears or housing.
- j. Kinked or pinched fluid line from tank to pump.
- k. Loose fitting on hose from tank to pump, usually indicated by foaming fluid in tank.

### 3. Air in fluid system – inability to bleed:

- a. Loss of replenish fluid supply – tank should be over half full.
- b. Missing or broken needles.
- c. Damaged or cut needle seals
- d. Loose fluid system fittings.
- e. Hole in fluid lines.
- f. Worn or damaged bleed valve O-rings.
- g. Plugged bleed valve or bleed system lines.
- h. Incorrect control valve adjustment, or plugged bleed hole in control valve.
- i. Damaged or worn cross pipe O-rings.
- j. Damaged or worn manifold O-rings.

**4. Inconsistent injection levels:**

- a. Condition of product.
- b. Adjustment of needle clearance, stripper plate clearance, or control valve.
- c. Worn or damaged linkage connecting valve to stripper.
- d. Stripper stops set too low.
- e. Conveyor not indexing consistently – check clutch; tighten brake.

**5. Unusual noises:**

- a. Intermittent high pitch “chirping” sound from conveyor – brake is dry or salty: rinse with water.
- b. Banging sound and machine sways back and forth – drive chain loose: adjust tension.
- c. Whining sound from pump – tank out of fluid: stop pump immediately, refill tank. Never run pump dry, even for short periods of time.
- d. Assist cylinders damaged or receiving improper air pressure.

**6. Rapid bearing failure:**

- a. Inadequate lubrication.
- b. Incorrect bearing or seal installation.
- c. Damaged or worn seal surfaces or bearing surfaces on shafts.
- d. Misaligned shaft.

**7. Rapid drive belt or chain failure:**

- a. Friction due to incorrect adjustment or alignment.
- b. Worn or damaged bearing and/or bearing surfaces on shafts.
- c. Worn or damaged pulleys or sprockets.
- d. Inadequate lubrication in drive components.

**8. Improper stripping of product from needles:**

- a. Burred needles.
- b. Insufficient stripper pressure.
- c. Adjustment of needle clearance or stripper plate clearance.
- d. Overlapping of product (bellies).



# SECTION 7 PARTS LIST

## — Contents —

How to Use Parts List . . . . .	102	Pump (RB10/15) . . . . .	133
To Place an Order . . . . .	103	Pump (RB30) . . . . .	135
Cross Reference . . . . .	104	Fluid Hoses . . . . .	137
Cabinet – RH Controls . . .	109	Electrical System . . . . .	143
Cabinet – LH Controls . . .	111	Air System . . . . .	149
Conveyor Drive . . . . .	113	Tags . . . . .	153
Conveyor Stroke Linkage .	115	Filter Unit (Model 11) . . . . .	155
Pump Drive . . . . .	117	Stripper Stops (Optional) . .	159
Conveyor (Metal Belt) . . . .	119	Infeed Tray . . . . .	160
Conveyor Guards (Metal Belt) . . . . .	121	Infeed Rollers . . . . .	161
Conveyor (Plastic Belt) . . . .	123	Exit Table . . . . .	162
Conveyor Guards (Plastic Belt) . . . . .	125	Casters . . . . .	163
Head Carriage . . . . .	127	Whole Bird . . . . .	NO TAG
Head & Valve (RB10/15) . . .	129	Valve Cam Linkage . . .	NO TAG
Head & Valve (RB30) . . . . .	131	Hardware Items . . . . .	164
		Index . . . . .	170



**Read instructions and review safety precautions (pages 5 through 11) before investigating problems or servicing machine.**



**Lock out electrical supply and disconnect air supply before performing any maintenance procedure. Re-connect these utilities only if maintenance procedure absolutely requires them.**

### **How to Use Parts List Section**

The following pages show an illustrated parts breakdown of the machine. Exploded view illustrations show all serviceable parts used within a particular assembly. A parts list, listing parts in numerical order, accompanies each illustration to show the complete part name, quantities used, and any other relevant application data.

When a part is used more than once, the item may only be illustrated once, for simplicity. Hardware items are called out on illustrations, but are not itemized on lists. A list of all hardware items is included on page 164.

If a part number is known, find its various applications by referring to the Part Number Cross Reference on the following pages. Parts are listed in numerical order, followed by the pages on which each item is listed.

## To Place a Parts Order

When ordering parts, or when communicating about any part of the machine, please include the following information:

1. Model Number of Machine
2. Serial Number of Machine
3. Part Number
4. Part Name in English

## Address, Telephone and Fax Information

Stork Townsend Inc.  
2425 Hubbell Avenue,  
Des Moines, IA 50317 USA

N. America: 800 247-8609  
Intl. 515 265-8181  
Fax: 515 263-3355

[www.townsendeng.com](http://www.townsendeng.com)

Stork Townsend B.V.  
Industrielaan 63 - 5349 AE, Oss, The Netherlands  
P.O. Box 292 - 5340 AG, Oss, The Netherlands

Telephone: +31 (0)412 669 911  
Fax: +31 (0)412 669 250

[www.townsend.nl](http://www.townsend.nl)

## To Order Copies of This Manual

Part number for this manual is: ..... 14288-6E-30.

Date for specific version of this manual is: ..... 2009-04-17.

**PART NUMBER CROSS REFERENCE**

<b>PART NO.</b>	<b>PAGES</b>	<b>PART NO.</b>	<b>PAGES</b>	<b>PART NO.</b>	<b>PAGES</b>	<b>PART NO.</b>	<b>PAGES</b>
02441	147	09399	133,135	10605	155	11038	127
02673	113,133,135	09419	113,117	10608	155	11044	109,111
02699	157	09420	127,149,151	10609	155	11048	109,111
02864	113	09423	127,151	10610	155	11056	113
03094	157	09450	113	10617	127	11059	113
03107	113	09451	127	10622	113	11077	127
03126	157	09455	123	10623	113	11080	127
03435	117	09456	119	10624	113	11081	129
04922	113	09463	113	10625	113	11102	133,137,139
05026	119,123	09465	145	10627	113	11105	133,137,139
05037	129,131	09560	109,111	10629	113	11109	129,131
06067	157	09562	109,111	10636	113	11110	129,131
06334	119,123	09563	109,111	10657	119,123	11111	129,131
06400	113	09672	129,131	10667	127	11119	113
06402	129,131	09688	119,123	10670	119	11120	113
06535	109,111	09702	119,123,127,129, 131	10674	129,131	11121	113
06558	113	09866	133,135	10694	153	11122	117
06559	113	09930	127,151	10705	157	11125	119
06560	113	09931	127	10731	127	11126	119
06566	113	09933	127	10732	127	11127	119
06953	119	09935	129,131,137,139, 141	10734	127	11128	119
06954	119	09939	127,149,151,157	10735	127	11129	119
07041	119,123	09960	127	10736	127	11130	119
07107	119	09965	113,117	10738	127	11133	119
07122	115	09970	133,135	10739	127	11134	119
07376	129,137	09980	127	10740	127	11136	155
07395	119,123	10026	133,135	10742	127,151	11137	155
07704	119,123	10029	129,131	10754	115	11153	109,111
07751	127	10033	127	10757	115,117	11155	109,111
07761	127	10076	129,131	10778	155	11162	127
07763	127	10079	129,131	10784	155	11165	117
07829	119,123	10080	131	10785	155	11171	127
07928	127	10082	129	10786	155	11184	129
07931	127,129,131	10090	119	10787	155	11185	129
07946	127	10101	137,155	10872	133,135	11194	113
08589	109,111	10107	129,131	10901	113,117	11195	127
08673	113	10143	129,131	10903	113,117	11204	117
08685	129	10177	129,133,137	10926	133	11205	117
08702	119,123	10187	155	10928	133	11209	113
09150	127,129,131,133, 135,137,139,141,147	10189	155	10931	133,135	11212	117
09186	129,131	10191	155	10937	133,135	11213	117,133,135
09252	115	10232	115	10938	133,135	11240	163
09267	127	10276	127	10945	133,135	11252	127
09275	129,131	10323	129,131	10946	133,135	11253	127
09276	129,131	10403	153	10947	133,135	11275	127,151
09311	129,131	10538	119,123	10954	133,135	11277	127
09312	129	10540	119,123	10973	113	11286	113,147
09313	129,131	10542	123	10974	113	11299	147
09314	129,131	10543	119	10975	113	11300	119
09315	129,131	10550	119,123	10976	113	11311	155
09325	129	10551	119,123	11029	127	11312	109,111,113,155
09338	127	10555	129,131	11031	127	11313	109,111,113,143, 155
09339	129,131	10556	113,117,119,123	11033	127	11314	109,111,143,157
09349	109,111	10604	155	11034	127	11317	157
09397	109,111,133,135			11035	127	11321	113
				11037	127		



**PART NUMBER CROSS REFERENCE**

PART NO.	PAGES	PART NO.	PAGES	PART NO.	PAGES	PART NO.	PAGES
11325	143	11826	133	12999	153	14037	129,131
11326	109,111,129,131,155	11834	163	13107	127	14038	121,125
11327	157	11838	163	13112	109,111	14042	121,125
11329	113,129,131	11860	127	13116	159	14043	123
11330	129,131	11861	133,135	13138	115	14044	119,121,123,125
11335	157	11875	161	13139	129,131	14045	119,121,123,125
11337	129,131	11878	161	13145	113	14046	123
11339	113,143	11885	161	13201	143,145	14047	121,125
11341	129,131,157	11899	117	13256	159	14048	123,125
11343	157	11900	117	13274	127	14057	119,123
11344	129,131	11921	159	13275	157	14060	155
11351	113	11922	159	13411	157	14063	115
11358	113	11928	159	13412	151,157	14081	123
11362	113,155,157	11929	159	13461	160	14082	123
11363	113,143	11931	159	13464	160	14083	123
11364	113	11943	109,111	13538	143	14084	123
11366	113	12090	147	13540	127,149,151,157	14086	123
11369	155	12422	117	13541	127,149,151	14089	123
11370	143	12476	113	13546	143	14091	123
11371	113	12477	113	13547	143	14094	109,111
11375	113	12484	119	13562	160	14095	119,123
11376	149,157	12485	119	13563	160	14096	115
11380	143,147	12486	119	13564	160	14097	155
11381	157	12491	109,111	13604	160	14098	123
11422	155	12493	109,111	13607-010	129,131,133,135	14099	123
11429	113,157	12518	147	13607-011	133,135	14111	155
11435	113	12787	119	13607-012	109,111,133,135	14115	127
11457	147	12834	113	13607-014	129,131	14116	159
11462	155	12835	113	13607-024	133,135	14117	159
11463	157	12836	113	13607-031	133,135	14118	159
11464	157	12837	113	13607-033	133,135	14122	123
11476	143	12838	113	13607-118	119,123	14123	129,137
11477	143	12839	113	13607-120	129,131,133	14131	155
11486	157	12853	133	13607-129	145	14132	155
11487	109,111,157	12854	133	13607-134	135,141	14134	155
11488	109,111,143,157	12855	133,135	13607-140	113,127	14135	155
11489	143,157	12856	133	13607-149	119,123	14136	155
11490	143	12857	133	13607-156	133,135	14145	121,125
11491	113,157	12858	133,135	13607-210	159	14156	155
11493	143,147	12859	133,135	13607-217	133,137,139	14158	155
11494	109,111,143	12860	133,135	13607-218	155	14162	123
11495	143	12861	133,135	13607-219	159	14168	157
11497	157	12862	133,135	13607-223	155	14172	113
11514	145	12863	133,135	13607-232	129,131,133	14173	157
11515	133,135	12864	133,135	13607-233	129,133	14174	119,123
11587	113	12865	133,135	13607-235	131	14175	157
11691	129,131	12867	133,135	13607-276	129,131,133	14176	157
11786	149	12869	133,135	13807	157	14178	160
11787	149,157	12870	133,135	13875	137,155	14181	160
11788	149	12875	133	13881	143	14182	157
11789	149,157	12877	135	13916-20	109,111	14183	157
11791	149	12877-15	133	14012	109,111	14186	157
11798	155,163	12943	133	14019	117	14187	157
11800	161	12944	133	14033	109,111	14188	157
11825	133	12964	161			14196	109,111
		12967	109,111				


**PART NUMBER CROSS REFERENCE**

<b>PART NO.</b>	<b>PAGES</b>	<b>PART NO.</b>	<b>PAGES</b>	<b>PART NO.</b>	<b>PAGES</b>	<b>PART NO.</b>	<b>PAGES</b>
14205	157	15104	143	16222	145,147,149	18816	109,111
14210	157	15145	143	16232	149	18817	109
14211	157	15221	109,111	16258	127	18820	109,111
14212	157	15271	149	16259	127	18821	143,145,147
14213	157	15288	147	16260	145,147	18823	143
14215	157	15348	131	16325	127,151	18824	143
14216	157	15349	131	16607	123	18825	143
14217	157	15368	113	16631	133,135,137,139, 141,147	18826	143
14222	157	15369	162	16632	127,129,131,133, 135,137,139,141,151	19062	147
14231	157	15376	162	16768	143	19065	147
14234	157	15419	131	17531	129	19091	117,147
14235	157	15420	131	17532	131	19092	123
14236	157	15421	131	17578	117,147	19093	123
14237	157	15429	121,125	17651	109,111	19112	145
14238	157	15453	121,125	17657	109,111	19113	143
14239	157	15456	121,125	17664	109	19115	145
14243	121,125	15485	162	17666	109	19116	109,111,149
14244	121,125	15510	153	17673	143	19118	149
14245	121,125	15622	119,123	17682	143	19126	143
14247	157	15623	119,123	17753	137,155	19128	145
14248	157	15629	121,125	17757	109,155	19178	127
14249	157	15726	157	17762	109,111	19276	127
14250	157	15877-10	133	17764	109,111	19315	147
14251	149	15923	133	17767	109,111	19433	119
14257	109,111	15965	135	17774	143	19459	117,147
14258	133,137	15966	135	17780	143	19460	151
14262	109,111,155	15967	135	17782	143	19520	133,135,137,139, 141
14264	159	15968	135	17784	143	19521	149
14269	157	15969	135	17788	143	20266	143
14270	157	15970	135	17794	143	20346	143
14271	157	15971	135	17795	143	20436	145
14276	155	15972	135	17796	143	20804	143
14313	133,135	15973	135	17797	143	20888	113,147
14379	153	15974	135,141	17799	143	21140	147
14384	121,125	15977	135,141	17801	143	21332	149
14417	157	15980	131,139,141	17802	143	21334	149
14458	119	15982	133,135,139,141	17803	143	21465	147
14459	119	15987	131,133,135,139, 141	17804	143	21692	153
14683	157	15992	139,141,155	17805	143	22003	109,111
14684	157	15995	139,141,155	17807	143	22006	143
14685	157	15996	139,141,155	18559	147	22007	143
14686	157	15997	133,139	18563	143,147	22008	143
14687	149,157	15998	133,139	18564	109,111,143,147	22011	111
14698	119,121	16102	115	18604	129,131	22013	111
14709	127	16103	115	18782	121,125	22154	147
14710	127	16106	115	18784	121,125	22217	111
14733	147	16107	115	18786	125	22218	111
14741	109,111,143	16117	115	18787	121,125	22220	111
14857	143	16135	147	18788	121	22229	137
14879	163	16166	149,151	18803	109,143,145	22230	137
14880	163	16167	149,157	18812	143,145,147	22420	111
15027	149	16168	157	18813	143,147	22750	155
15036	149,151	16175	157	18814-1	109,111	22859	157
15037	149,151	16216	129,131	18815	109	22863	129,131
15039	149,151	16221	145,147,149			22866	129,131
15103	143						

## PART NUMBER CROSS REFERENCE


PART NO.	PAGES	PART NO.	PAGES	PART NO.	PAGES	PART NO.	PAGES
23228	121,125	25510	127	29367	145	32849	119,123
23229	121,125	25542	109,111	31403	157	33747	157
23231	121,125	25546	109,111,143	31701	143	37516	129,131
23352	155	26489	119	31761	155	37517	129,131
23353	117,147	27767	113	31762	155	37857	129,131
25399	143	28448	109,111	31767	137,155	41981	113
25452	147	28718	143,145	31768	139,141,155	43869	157
25453	147	28719	143,145	31772	129,131	46416	157
25488	129,137	28720	143,145	32279	115	46417	157
25489	131,141	29358	145	32281	115	46418	157
25503	109,111,143	29361	145	32834	129,131	46419	157
25504	109,111	29366	145	32847	119,123	47030	113

## Cabinet – RH Controls




## Cabinet – RH Controls

PART NO.	PART NAME	PART NO.	PART NAME
06535	PAD, resilient (4)	14196	GASKET, bulk (quantity=feet)
08589	KNOB (3)	14257	TUBE, jam (4)
09349	POST (2)	14262	SEALANT, 10 oz
09397	SPACER (2)	14741	NUT, lock, 8-32
09560	SHAFT (1)	15221	KNOB (2)
09562	KNOB (1)	17651	FRAME(1)
09563	SPRING (1)	17657	PANEL, bottom (1)
11044	GASKET set (1)	17664	TRAY, drain (1opt)
11048	GASKET set (1)	17666	TRAY, drain, long (1opt)
11153	GASKET set (1)	17757	TROUGH, drain (1)
11155	PANEL, bottom (1)	17762	PANEL, end (1)
11312	SCREW, hex head, 1/4-20x1/2	17764	COVER (1)
11313	SCREW, hex head, 1/4-20x5/8	17767	COVER (2)
11314	SCREW, hex head, 1/4-20x3/4	18564	MAGNET (5)
11326	SCREW, hex head, 5/16-18x5/8	18803	BRACKET, mounting (1)
11487	WASHER, flat, 1/4	18814-1	GUARD, infeed (1)
11488	WASHER, flat, 1/4	18815	PANEL, side, LH (1)
11494	WASHER, lock, 1/4	18816	PANEL, side, RH (1)
11943	GUARD (1)	18817	PANEL, side, LH (1)
12491	GUARD, RH (1)	18820	GUARD, lower infeed (1)
12493	GUARD, LH (1)	19116	PANEL, air (1)
12967	GUARD, front (1)	22003	PLATE, blanking (1)
13112	BOSS (12)	25503	SHELL (4)
13607-012	O-RING(1)	25504	SCREW, flat security, 8-32x5/8 (4)
13916-20	PIN (1)	25542	WASHER (1)
14012	GASKET (1)	25546	SCREW, flat security, 8-32x1 (1)
14033	PIVOT (2)	28448	HOOD (1)
14094	FOOT, adjustable (4)		




## Cabinet – LH Controls




## Cabinet – LH Controls

PART NO.	PART NAME	PART NO.	PART NAME
06535	PAD, resilient (4)	14196	GASKET, bulk (quantity=feet)
08589	KNOB (3)	14257	TUBE, jam (4)
09349	POST (2)	14262	SEALANT, 10 oz
09397	SPACER (4)	14741	NUT, lock, 8-32
09560	SHAFT (1)	15221	KNOB, hand (2)
09562	KNOB (1)	17651	FRAME (1)
09563	SPRING (1)	17657	PANEL, bottom (1)
11044	GASKET set (1)	17762	PANEL, end (1)
11048	GASKET set (1)	17764	COVER (1)
11153	GASKET set (1)	17767	COVER (2)
11155	PANEL, bottom (1)	18564	MAGNET (7)
11312	SCREW, hex head, 1/4-20x1/2	18814-1	GUARD, infeed (1)
11313	SCREW, hex head, 1/4-20x5/8	18816	PANEL, side, rear (2)
11314	SCREW, hex head, 1/4-20x3/4	18820	GUARD, lower infeed (1)
11326	SCREW, hex head, 5/16-18x5/8	19116	PANEL, air (1)
11487	WASHER, flat, 1/4	22003	PLATE, blanking (1)
11488	WASHER, flat, 1/4	22011	PANEL side, front upper (1)
11494	WASHER, lock, 1/4	22013	PANEL, side, front lower (1)
11943	GUARD (1)	22217	TROUGH, drain (1)
12491	GUARD, RH (1)	22218	TRAY, drain (1opt)
12493	GUARD, LH (1)	22220	TRAY, drain, long (1opt)
12967	GUARD, front (1)	22420	BRACKET, mounting (1)
13112	BOSS (12)	25503	SHELL (4)
13607-012	O-RING (1)	25504	SCREW, flat security, 8-32x5/8 (4)
13916-20	PIN (1)	25542	WASHER (1)
14012	GASKET (1)	25546	SCREW, flat security, 8-32x1 (1)
14033	PIVOT (2)	28448	HOOD (1)
14094	FOOT, adjustable (4)		




## Conveyor Drive







## Conveyor Drive

PART NO.	PART NAME	PART NO.	PART NAME
02673	KEY, woodruff (2)	11286	MOTOR, 1.5 hp, 575 V (1 opt)
02864	FITTING, 1/4-28x1/8 NPT (3)	11312	SCREW, hex head, 1/4-20x1/2
03107	KEY, square (1)	11313	SCREW, hex head, 1/4-20x5/8
04922	WASHER, flat, 3/8 (2)	11321	SCREW, hex head, 1/4-20x2-1/4
06400	SEAL (2)	11329	SCREW, hex head, 5/16-18x1
06558	PULLEY, 84T (1)	11339	SCREW, hex head, 3/8-16x1/2
06559	HUB (1)	11351	SCREW, hex head, 3/8-16x3-1/2
06560	BEARING assembly (2)	11358	SCREW, hex head, 1/2-13x2-1/2
06566	KEY, woodruff (3)	11362	NUT, hex, 1/4-20
08673	BELT (1)	11363	NUT, hex, 5/16-18
09419	FITTING, 90 degree, 1/8 NPT (7)	11364	NUT, hex, 3/8-16
09450	NUT, jam, 7/8-14 (1)	11366	NUT, hex, 1/2-13
09463	PULLEY, 18T (1/60Hz)	11371	NUT, hex jam, 3/8-16
09965	ADAPTER, bulkhead (5)	11375	NUT, hex, 5/8-11
10556	FITTING, grease (7)	11429	SETSCREW, socket, 1/2-20x3/8
10622	BEARING, sleeve (1)	11435	SETSCREW, socket, 5/16-18x1/2
10623	SPROCKET, 15T (1)	11491	WASHER, flat, 3/8
10624	SPROCKET, 15T (1)	11587	SCREW, hex head, 1/4-20x2-1/2
10625	SPROCKET, 45T (1)	12476	PULLEY, 20T (1opt)
10627	BRACKET assembly (1)	12477	PULLEY, 21T (1opt)
10629	HOUSING, bearing (2)	12834	HOUSING assembly, bearing (2)
10636	SPROCKET assembly (1)	12835	SEAL (2)
10901	HOSE assembly (5)	12836	BEARING, sleeve (2)
10903	FITTING, swival (5)	12837	BEARING assembly (2)
10973	ARM, crank (2)	12838	BLOCK, bearing (2)
10974	HOUSING, bearing (1)	12839	BUSHING (2)
10975	HOUSING, bearing (1)	13145	PULLEY, 22T (1opt)
10976	CAP (2)	13607-140	O-RING (2)
11056	BEARING (2)	14172	SCREW, hex head, 1/4-28x3/4
11059	CHAIN (1)	15368	PULLEY, 14T (1opt)
11119	HOUSING assembly, bearing (1)	20888	MOTOR, 1.5 hp, 190-460 V (1opt)
11120	HOUSING assembly, bearing (1)	27767	SETSCREW, socket, M8x10 mm
11121	CRANKSHAFT (1)	41981	SETCOLLAR (2)
11194	COUNTERSHAFT (1)	47030	BRACKET (1)
11209	NUT, bar (2)		




## Conveyor Stroke Linkage





## Conveyor Stroke Linkage

PART NO.	PART NAME	PART NO.	PART NAME
07122	BUSHING (4)	16102	LINKAGE assembly (1)
09252	SCREW, shoulder (4)	16103	PLATE, pivot (1)
10232	FITTING, grease, 90° (1)	16106	ARM & BUSHING assembly (1)
10754	BUSHING (1)	16107	ARM (1)
10757	WASHER (1)	16117	TAG (1)
13138	WASHER (1)	32279	ROD (1)
14063	BRACKET (1)	32281	SLEEVE (1)
14096	BRACKET assembly (1)		






## Pump Drive




## Pump Drive

PART NO.	PART NAME	PART NO.	PART NAME
03435	WASHER, flat (4)	11212	KEY, square (2)
09419	ELBOW, 90° (2)	11213	KEY, square—sq (1)
09965	ADAPTER, bulkhead (2)	11899	SHAFT (1)
10556	FITTING, grease (2)	11900	COUPLING (1)
10757	WASHER, flat (4)	12422	KEY, square (1)
10901	HOSE assembly (2)	14019	BRACKET, mounting, pump (1)
10903	FITTING, swival (4)	17578	MOTOR, 5 hp, 190-460 v (1opt)
11122	NUT, bar (2)	19091	MOTOR, 5 hp, 380 V/60 (1opt)
11165	GASKET (1)	19459	WATERTIGHT (1)
11204	SPIDER (2)	23353	MOTOR, 5 hp, 575 V (1opt)
11205	COUPLING (3)		

**YOU ARE HERE:** ▶




## Conveyor – Metal Belts




## Conveyor – Metal Belts

PART NO.	PART NAME	PART NO.	PART NAME
05026	SEAL (1)	11129	IDLER ROLLER (2opt)
06334	SET COLLAR (8)	11130	IDLER ROLLER ASM (2opt)
06953	SPROCKET–½”P (4opt)	11133	SHAFT–1”P (1opt)
06954	SPROCKET–½”P (2opt)	11134	DRIVE SHAFT ASM–1”P (1opt)
07041	BUSHING (2)	11300	CONNECTING ROD–1”P (1opt)
07107	BUSHING (4)	12484-12.75	CONV BELT, ½”P no cleats (1opt)
07395	SET COLLAR (1)	12485-12.75	CONV BELT, 1”P no cleats (1opt)
07704	FLANGE (2)	12486-12.75	CONV BELT, ½”P semi-cleat (1opt)
07829	IDLER SHAFT (1)	12787-12.75	CONV BELT, 1”P semi-cleat (1opt)
08702	BRAKE BLOCK (2)	13607-118	O-RING (1)
09455	STUD (1)	13607-149	O-RING (1)
09688	SPRING (2)	14044	SIDE RAIL–LH FRONT (1opt)
09702	SPACER (4)	14045	SIDE RAIL–RH FRONT (1opt)
10090	CONNECTING ROD–½”P (1opt)	14057	CONV SUPPORT–LOWER (1)
10538	CLUTCH (1)	14095	ADJUSTMENT SCREW (2)
10540	COVER (1)	14174	STRAP (2)
10543	GROOVE PIN (1)	14698	CONV SUPPORT–UPPER (1)
10550	KEY–SQ (1)	14458-12.75	CONV BELT, ½”P full-cleat (1opt)
10551	KEY–WOODRUFF (1)	14459-12.75	CONV BELT, 1”P full-cleat (1opt)
10556	GREASE FITTING (1)	15622	GUARD (2)
10657	FLANGE BRG ASM (2)	15623	MTG BLOCK (2)
10670	IDLER SPROC ASM–½”P (4opt)	19433	SPROCKET–½”P (1opt)
11125	SPROCKET–1”P (2opt)	26489	DRIVE SHAFT ASM–½”P (1opt)
11126	SPROCKET–1”P (2opt)	32847	HSG (1)
11127	SPROCKET–1”P (1opt)	32849	CAP, CLUTCH HSG (1)
11128	IDLER SPROC ASM–1”P (2opt)		







## Guards – Metal Belt Conveyor






## Guards – Metal Belt Conveyor

PART NO.	PART NAME	PART NO.	PART NAME
14038	FRONT CONV GUARD (2opt)	15429	GUARD–W/ STOPS (2opt)
14042	REAR CONV GUARD–LH (1)	15453	GUARD–LH–W/O STOPS (1opt)
14044	SIDE RAIL–LH FRONT (1opt)	15456	GUARD–RH–W/O STOPS (1opt)
14045	SIDE RAIL–RH FRONT (1opt)	15629	GUARD (1)
14047	SIDE RAIL–LH REAR (1opt)	18782	FRONT GUARD–RH (1opt)
14145	SIDE RAIL–RH REAR (1opt)	18784	FRONT GUARD–LH (1opt)
14243	GUARD–LH (1)	18787	SPACER (2opt)
14244	GUARD–RH (1)	18788	HX HD SCR, 1/4-20x7/8 (6opt)
14245	REAR CONV GUARD–RH (1)	23228	SIDE RAIL, RH rear (1 /23231)
14384	SPACER (12+6opt)	23229	SIDE RAIL, LH rear (1 /23231)
14698	CONV SUPPORT–UPPER (1)	23231	GUARD, w/stops (2 /23228,23229)






## Conveyor – Plastic Belts




## Conveyor – Plastic Belts

PART NO.	PART NAME	PART NO.	PART NAME
05026	SEAL (1)	14057	CONV SUPPORT–LOWER (1)
06334	SET COLLAR (8)	14081	PIN–GROOVE (1)
07041	BUSHING (2)	14082	CONV BELT ASM–NON CLEATED (1opt)
07395	SET COLLAR (1)	14083	RETAINING RING (10)
07704	FLANGE (2)	14084	SPROCKET–PLASTIC (6)
07829	IDLER SHAFT (1)	14086	HUB–DRIVE SPROCKET (1)
08702	BRAKE BLOCK (2)	14089	HUB–FIXED (2)
09455	STUD (1)	14091	HUB–IDLER SPROCKET (3)
09688	SPRING (2)	14095	ADJUSTMENT SCREW (2)
09702	SPACER (4)	14098	BUSHING (3)
10538	CLUTCH–CLUTCH (1)	14099	HUB ASM–IDLER SPROCKET (3)
10540	COVER (1)	14122	NYLON BOLT (26)
10542	SHAFT (1)	14162	HINGE ROD (1)
10550	KEY–SQ (1)	14174	STRAP (2)
10551	KEY–WOODRUFF (1)	15622	GUARD (2)
10556	GREASE FITTING (1)	15623	MTG BLOCK (2)
10657	FLANGE BRG ASM (2)	16607	CONV BELT ASM–CLEATED (1opt)
13607-118	O-RING (1)	19092	CONV BELT MODULE–NON CLEATED (1opt)
13607-149	O-RING (1)	19093	CONV BELT MODULE–CLEATED (1opt)
14043	SKID PLATE (3)	32847	HSG (1)
14044	SIDE RAIL–LH FRONT (1)	32849	CAP, CLUTCH HSG (1)
14045	SIDE RAIL–RH FRONT (1)		
14046	SKID RAIL (4)		
14048	CONV SUPPORT–UPPER (1)		

**YOU ARE HERE:** ▶




## Guards – Plastic Belt Conveyor






## Guards – Plastic Belt Conveyor


PART NO.	PART NAME	PART NO.	PART NAME
14038	FRONT CONV GUARD (2)	15429	GUARD, w/stops (2 /14047, 14145)
14042	REAR CONV GUARD–LH (1)	15453	GUARD–LH–W/O STOPS (1opt)
14044	SIDE RAIL–LH FRONT (1)	15456	GUARD–RH–W/O STOPS (1opt)
14045	SIDE RAIL–RH FRONT (1)	15629	GUARD (1)
14047	SIDE RAIL–LH REAR (1opt)	18782	GUARD–RH FRONT (1opt)
14048	CONV SUPPORT–UPPER (1)	18784	GUARD–LH FRONT (1opt)
14145	SIDE RAIL–RH REAR (1opt)	18787	SPACER (2opt)
14243	GUARD–LH (1)	18788	HX HD SCR, 1/4-20x7/8 (6opt)
14244	GUARD–RH (1)	23228	SIDE RAIL, RH rear (1 /23231)
14245	REAR CONV GUARD–RH (1)	23229	SIDE RAIL, LH rear (1 /23231)
14384	SPACER (16+12opt)	23231	GUARD, w/stops (2 /23228, 23229)



**YOU ARE HERE:**




## Head Carriage




## Head Carriage

PART NO.	PART NAME	PART NO.	PART NAME
07751	LINK (2)	11029	PUSH ROD (2)
07761	PIVOT LINK (2)	11031	CUSHION (2)
07763	BUSHING (8)	11033	PISTON CUP (2)
07928	BRG (2)	11034	WASHER (2)
07931	BRG (4)	11035	TIE ROD (2)
07946	SEAL (2)	11037	YOKE (2)
09150	TUBE, clear, 3/8" (quantity=feet)	11038	STPR YOKE ASM (2)
09267	SHOULDER BOLT (2)	11077	STPR ASM (1)
09338	FRAME-HEAD CARRIAGE (1)	11080	FRAME-STPR (1)
09420	TUBE, clear, 1/4" (quantity=feet)	11162	STPR PLATE ASM (1)
09423	BLOCK (1)	11171	COVER (2)
09451	NUT-LH (2)	11195	GUIDE (2)
09702	SPACER (6)	11252	NUT (4)
09930	BLOCK (1)	11253	PLATE-STPR (1)
09931	CONNECTOR (3)	11275	CYL-STPR (2)
09933	ELBOW (2)	11277	FRAME ASM-STPR (1)
09939	ADAPTER-BULKHEAD (2)	11860	CYL HSG ASM (2)
09960	SNAP RING (8)	13107	IMPACT PAD (2opt)
09980	CAP (2)	13274	ROD WIPER (2)
10033	PIVOT SHAFT (2)	13540	ELBOW-90°-1/4"NPT (2)
10276	BUSHING (4)	13541	ELBOW-90°-1/8"NPT (3)
10617	SEAL (4)	13607-140	O-RING (2)
10667	ROD END ASM (2)	14115	STPR STOP ASM (2opt)
10731	PISTON-UPPER (4)	14709	STPR GUARD-RH (1opt)
10732	PISTON-LOWER (2)	14710	STPR GUARD-LH (1opt)
10734	CYL ASM (2)	16258	REPAIR KIT-STPR CYL (1opt)
10735	OILER PAD (4)	16259	REPAIR KIT-ASSIST CYL (1opt)
10736	WASHER (4)	16325	FITTING-1/8"NPT (3)
10738	PISTON ROD (2)	16632	ELBOW-90°-1/4"NPT (1)
10739	PISTON ROD ASM (2)	19178	PLUG (2)
10740	CYL HSG ASM (2)	19276	ROD & BRG ASM (2)
10742	ASSIST CYL (2)	25510	GUIDE (1)




## Head & Valve – RB10/15






## Head & Valve – RB10/15

PART NO.	PART NAME	PART NO.	PART NAME
05037	PIN (1)	11111	LEVER (1)
06402	SEAL (175)	11184	VALVE BODY ASM (1)
07376	CONNECTOR (2)	11185	CONTROL VALVE ASM (1)
07931	BRG (2)	11326	HX HD SCR, 5/16-18 x 5/8 (8)
08685	SEAL (2)	11329	HX HD SCR, 5/16-18 x 1 (2)
09150	TUBE, 3/8" (quantity=feet)	11330	HX HD SCR, 5/16-18 x 1-1/4 (4)
09186	QUAD RING (1)	11337	HX HD SCR, 5/16-18 x 3-1/4 (2)
09275	CAP (1)	11341	HX HD SCR, 3/8-16 x 3/4 (1)
09276	PLATE (1)	11344	HX HD SCR, 3/8-16 x 1-1/2 (1)
09311	OUTLET FLANGE (1)	11691	NEEDLE CLEANER (1)
09312	PISTON (1)	13139	NEEDLE PLUG (opt—as req'd)
09313	BUSHING (1)	13607-010	O-RING (opt—as req'd)
09314	BUSHING (1)	13607-014	O-RING (12)
09315	CROSS PIPE (1)	13607-120	O-RING (2)
09325	COVER (1)	13607-232	O-RING (1)
09339	SPACER (2)	13607-233	O-RING (1)
09672	VALVE INSERT (1)	13607-276	O-RING (1)
09702	SPACER (1)	14037	CRANK ARM (1)
09935	ELBOW (1)	14123	HOSE assembly (1)
10029	GASKET (1)	16216	SCREEN (1opt)
10076	TUBE (1)	16632	ELBOW—90°—1/4"NPT (2)
10079	WIRE (2)	17531	KIT—RB10/15 VALVE
10080	NEEDLE PULLER ASM	18604	NEEDLE ASM, SIDE PORT, 10 PACK (opt)
10107	CONNECTING LINK (1)	22863	HX HD SCR, M10 x 25mm (4)
10143	NEEDLE ASM, HYPO, .025 WALL, 10 PACK (opt)	22866	HX HD SCR, M10 x 40mm (8)
10177	HOSE assembly (1)	25488	ELBOW—45°—SWIVEL (2)
10323	WASHER (8)	31772	WRENCH, "T" HANDLE (1)
10555	NEEDLE STAIGHTENER (1)	32834	NEEDLE ASM, HYPO, .020 WALL, 10 PACK (opt)
10674	CONNECTING LINK ASM (1)	37516	INJECTOR HEAD (1)
11081	VALVE BODY (1)	37517	MANIFOLD (1)
11109	STEM (1)	37857	CROSS PIN, HEAD (12)
11110	HANDLE (1)		




## Head & Valve – RB30




## Head & Valve – RB30

PART NO.	PART NAME	PART NO.	PART NAME
05037	PIN (1)	11341	HX HD SCR, 3/8-16 x 3/4 (1)
06402	SEAL (175)	11344	HX HD SCR, 3/8-16 x 1-1/2 (1)
07931	BRG (2)	11691	NEEDLE CLEANER (1)
09150	TUBING—3/8" (specify quantity in feet)	13139	NEEDLE PLUG (opt—as req'd)
09186	QUAD RING (1)	13607-010	O-RING (opt—as req'd)
09275	CAP (1)	13607-014	O-RING (12)
09276	PLATE (1)	13607-120	O-RING (2)
09311	OUTLET FLANGE (1)	13607-232	O-RING (1)
09313	BUSHING (1)	13607-235	O-RING (1)
09314	BUSHING (1)	13607-276	O-RING (1)
09315	CROSS PIPE (1)	14037	CRANK ARM (1)
09339	SPACER (2)	15348	COVER (1)
09672	VALVE INSERT (1)	15349	PISTON (1)
09702	SPACER (1)	15419	SEAL (2)
09935	ELBOW (1)	15420	VALVE BODY ASM (1)
10029	GASKET (1)	15421	CONTROL VALVE ASM (1)
10076	TUBE (1)	15980	HOSE assembly (1)
10079	WIRE (2)	15987	HOSE assembly (1)
10080	NEEDLE PULLER ASM	16216	SCREEN (1opt)
10107	CONNECTING LINK (1)	16632	ELBOW—90°—1/4"NPT (2)
10143	NEEDLE ASM, HYPO, .025 WALL, 10 PACK (opt)	17532	KIT—RB30 VALVE
10323	WASHER (8)	18604	NEEDLE ASM, SIDE PORT, 10 PACK (opt)
10555	NEEDLE STAIGHTENER (1)	22863	HX HD SCR, M10 x 25mm (4)
10674	CONNECTING LINK ASM (1)	22866	HX HD SCR, M10 x 40mm (8)
11109	STEM (1)	25489	ELBOW—45°—SWIVEL (2)
11110	HANDLE (1)	31772	WRENCH, "T" HANDLE (1)
11111	LEVER (1)	32834	NEEDLE ASM, HYPO, .020 WALL, 10 PACK (opt)
11326	HX HD SCR, 5/16-18 x 5/8 (8)	37516	INJECTOR HEAD (1)
11329	HX HD SCR, 5/16-18 x 1 (2)	37517	MANIFOLD (1)
11330	HX HD SCR, 5/16-18 x 1-1/4 (4)	37857	CROSS PIN, HEAD (12)
11337	HX HD SCR, 5/16-18 x 3-1/4 (2)		



## Pump – RB10/15



## Pump – RB10/15


PART NO.	PART NAME	PART NO.	PART NAME
02673	KEY–WOODRUFF (2)	12858	SEAL SLEEVE (2)
09150	TUBING–3/8” (specify quantity in feet)	12859	PIN (2)
09397	SPACER (2)	12860	INNER SPACER (2)
09399	PIN (1)	12861	GLAND (2)
09866	VALVE BODY (1)	12862	ROLLER BRG (4)
09970	VALVE STEM (1)	12863	OUTER SPACER (2)
10026	BLEED VALVE ASM (1)	12864	ROLLER BRG (2)
10177	HOSE assembly (1opt)	12865	SEAL (1)
10872	STOP (1)	12867	SLEEVE (1)
10926	HSG–GEAR–RB15 (1opt)	12869	PLUG ASM (1)
10928	GEAR–RB15 (2opt)	12870	RELIEF PORT (2)
10931	SEAL (2)	12875	BRG HSG ASM (1)
10937	LOCK NUT (2)	12943	COVER–RB10 (1opt)
10938	LOCK WASHER (2)	12944	COVER–RB15 (1opt)
10945	SEAL PLATE (1)	13607-010	O-RING (1)
10946	SEAL PLATE ASM (1)	13607-011	O-RING (1)
10947	SEAL CAP (1)	13607-012	O-RING (1)
10954	SEAL (2)	13607-024	O-RING (2)
11102	INLET (1)	13607-031	O-RING (1)
11105	OUTLET (1)	13607-033	O-RING (2)
11213	KEY–SQ (1)	13607-156	O-RING (2)
11515	PIPE PLUG (1)	13607-217	O-RING (2)
11825	HSG–GEAR–RB10 (1opt)	14258	HOSE assembly (1opt)
11826	GEAR–RB10 (2opt)	14313	PLUG DETAIL (1)
11861	GREASE–12 OZ TUBE	15982	HOSE assembly (1opt)
12853	PUMP ASM–RB10 (1opt)	15987	HOSE assembly (1opt)
12854	PUMP ASM–RB15 (1opt)	15997	ADAPTER (1opt)
12855	HSG–DRIVE (1)	15998	ADAPTER (1opt)
12856	DRIVE SHAFT (1)	16631	FITTING (2)
12857	IDLER SHAFT (1)	16632	ELBOW (1)
		19520	ELBOW (1)

**12877-10 OR 12877-15 PUMP OVERHAUL KIT (includes the following)**


10928	GEAR–RB15 (2opt)	12864	ROLLER BRG (2)
10931	SEAL (2)	12865	SEAL (1)
10954	SEAL (2)	12867	SLEEVE (1)
11826	GEAR–RB10 (2opt)	13607-024	O-RING (2)
12858	SEAL SLEEVE (2)	13607-031	O-RING (1)
12859	PIN (2)	13607-033	O-RING (2)
12862	ROLLER BRG (4)	13607-156	O-RING (2)

**15923 SEAL KIT – PUMP & VALVE (includes the following)**

08685	SEAL (2)	13607-033	O-RING (2)
09186	QUAD RING (1)	13607-120	O-RING (2)
10954	SEAL (2)	13607-156	O-RING (2)
13607-010	O-RING (1)	13607-217	O-RING (2)
13607-011	O-RING (1)	13607-232	O-RING (1)
13607-012	O-RING (1)	13607-233	O-RING (1)
13607-024	O-RING (2)	13607-276	O-RING (1)
13607-031	O-RING (1)		




## Pump – RB30






## Pump – RB30

PART NO.	PART NAME	PART NO.	PART NAME
02673	KEY–WOODRUFF (2)	12867	SLEEVE (1)
09150	TUBING–3/8" (specify quantity in feet)	12869	PLUG ASM (1)
09397	SPACER (2)	12870	RELIEF PORT (2)
09399	PIN (1)	13607-010	O-RING (1)
09866	VALVE BODY (1)	13607-011	O-RING (1)
09970	VALVE STEM (1)	13607-012	O-RING (1)
10026	BLEED VALVE ASM (1)	13607-024	O-RING (2)
10872	STOP (1)	13607-031	O-RING (1)
10931	SEAL (2)	13607-033	O-RING (2)
10937	LOCK NUT (2)	13607-134	O-RING (2)
10938	LOCK WASHER (2)	13607-156	O-RING (2)
10945	SEAL PLATE (1)	14313	PLUG DETAIL (1)
10946	SEAL PLATE ASM (1)	15965	BUSHING (2)
10947	SEAL CAP (1)	15966	GEAR (2)
10954	SEAL (2)	15967	HSG–GEAR (1)
11213	KEY–SQ (1)	15968	HX HD SCR (8)
11515	PIPE PLUG (1)	15969	DRIVE SHAFT (1)
11861	GREASE–12 OZ TUBE	15970	IDLER SHAFT (1)
12855	DRIVE HSG (1)	15971	PUMP COVER ASM (1)
12858	SEAL SLEEVE (2)	15972	BRG HSG ASM (1)
12859	PIN (2)	15973	PUMP ASM (1)
12860	INNER SPACER (2)	15974	INLET (1)
12861	GLAND (2)	15977	OUTLET (1)
12862	ROLLER BRG (4)	15982	HOSE assembly (1)
12863	OUTER SPACER (2)	15987	HOSE assembly (1)
12864	ROLLER BRG (2)	16631	FITTING (2)
12865	SEAL (1)	16632	ELBOW (1)
		19520	ELBOW (1)
12877	PUMP OVERHAUL KIT (includes the following)		
10931	SEAL (2)	12867	SLEEVE (1)
10954	SEAL (2)	13607-024	O-RING (2)
12858	SEAL SLEEVE (2)	13607-031	O-RING (1)
12859	PIN (2)	13607-033	O-RING (2)
12862	ROLLER BRG (4)	13607-156	O-RING (2)
12864	ROLLER BRG (2)	15965	BUSHING (2)
12865	SEAL (1)	15966	GEAR (2)




## Fluid Hoses – RB10/15 with small hoses






## Fluid Hoses – RB10/15 with small hoses

PART NO.	PART NAME	PART NO.	PART NAME
07376	FITTING (2)	14258	HOSE assembly (1/RH controls)
09150	TUBING, plastic (quantity=feet)	16631	FITTING (2)
09935	ELBOW-90° (1)	16632	ELBOW-90° (2)
10101	ELBOW-90° (1)	17753	BAFFLE (1)
10177	HOSE-3/4"x120" (1)	19520	ELBOW-90° (1)
11102	INLET (1)	22229	HOSE assembly (1/LH controls)
11105	OUTLET (1)	22230	HOSE assembly (1/LH controls)
13607-217	O-RING (2)	25488	ELBOW-45°-SWIVEL (2)
13875	ELBOW-90° (1)	31767	REDUCER, EXTENDED (1)
14123	HOSE assembly (1/RH controls)		




## Fluid Hoses – RB10/15 with large hoses




## Fluid Hoses – RB10/15 with large hoses

PART NO.	PART NAME	PART NO.	PART NAME
09150	TUBING—PLASTIC (specify quantity in feet)	15995	BAFFLE (1)
09935	ELBOW—90° (1)	15996	SEAL (1)
11102	INLET (1)	15997	ADAPTER (1)
11105	OUTLET (1)	15998	ADAPTER (1)
13607-217	O-RING (2)	16631	FITTING (2)
15980	HOSE assembly (1/RH controls)	16632	ELBOW—90° (2)
15982	HOSE assembly (1/RH controls)	19520	ELBOW—90° (1)
15987	HOSE assembly (1)	22227	HOSE assembly (1/LH controls)
15992	ELBOW—45° (1)	22228	HOSE assembly (1/LH controls)
		31768	ELBOW, EXTENDED—45° (1)




## Fluid Hoses – RB30




## Fluid Hoses – RB30

PART NO.	PART NAME	PART NO.	PART NAME
09150	TUBING, plastic (quantity=feet)	15995	BAFFLE (1)
09935	ELBOW–90° (1)	15996	SEAL (1)
13607-134	O-RING	16631	FITTING (2)
15974	INLET (1)	16632	ELBOW–90°
15977	OUTLET (1)	19520	ELBOW–90°
15980	HOSE assembly (1/RH controls )	22227	HOSE assembly (1/LH controls )
15982	HOSE assembly (1/RH controls )	22228	HOSE assembly (1/LH controls )
15987	HOSE assembly (1)	25489	ELBOW–45°–SWIVEL (2)
15992	ELBOW–45° (1)	31768	ELBOW, EXTENDED–45° (1)




## Electrical – Main Panel




## Electrical – Main Panel

PART NO.	PART NAME	PART NO.	PART NAME
11313	SCREW, hex head, 1/4-20x5/8	17784	FUSEHOLDER (2)
11314	SCREW, hex head, 1/4-20x3/4	17788	END (1)
11325	SCREW, hex head, 5/16-18x3/4	17794	BLOCK, terminal (20)
11339	SCREW, hex head, 3/8-16x1/2	17795	BLOCK, earth (3)
11363	NUT, hex, 5/16-18	17796	LABEL, 1-10 (1)
11370	NUT, jam, 5/16x18	17797	LABEL, 11-20 (1)
11380	NUT, hex, 10-24	17799	LABEL, PE, N, L1... (1)
11476	SCREW, binder head, 8-32x3/8	17801	LABEL, 1-10 (1)
11477	SCREW, binder head, 8-32x1/2	17802	LABEL, 11-20 (1)
11488	WASHER, flat, 9/32	17803	LABEL, 1-10 (1)
11489	WASHER, flat, 11/32	17804	LABEL, 11-20 (1)
11490	WASHER, flat, 11/32	17805	PLATE (1)
11493	WASHER, lock, internal tooth, #10	17807	BLOCK, terminal (9)
11494	WASHER, lock, 1/4	18563	SWITCH, magnetic (1)
11495	WASHER, lock, 5/16	18564	MAGNET (1)
15145	WASHER, flat, 3/8	18803	BRACKET, mounting (1)
13201	COVER (1)	18812	ENCLOSURE (1)
13538-1	FUSE, 1 A (1)	18813	PANEL (1)
13538-2	FUSE, 2 A (1)	18821	DOOR (1)
13543-3	FUSE, 3 A (2)	18823	LABEL, F1 (1)
13546	TRANSFORMER, 200-380 V (1opt)	18824	LABEL, F2 (1)
13547	TRANSFORMER, 415-575 V (1opt)	18825	LABEL, F3 (1)
13881	SCREW, slotted, 10-32x3/8	18826	LABEL, F4 (1)
14741	NUT, lock, 8-32	19113	NUT, tapered (1)
14857	CONTACTOR, 12 A 60 Hz (1opt)	19126	LABEL, U1, U2... (1)
15103	CONTACTOR, 32 A 60 Hz (1opt)	20266	CONTACTOR, 32 A 50 Hz (1opt)
15104-1	RELAY, overload, 2.5-4 A (1opt)	20436	SWITCH assembly, disconnect (1)
15104-2	RELAY, overload, 4-6a (1opt)	20804	TRANSFORMER, 380/400/410 V (1opt)
15104-3	RELAY, overload, 5.5-8 A (1opt)	22006	WASHER, flat (1)
15104-4	RELAY, overload, 7-10 A (1opt)	22007	NUT (1)
15104-5	REALY, overload, 9-13 A (1opt)	22008	GASKET (1)
15104-6	RELAY, overload, 12-18 A (1opt)	25399	POWER SUPPLY, DC (1)
16768	CONTACTOR, 12 A 50 Hz (1opt)	25503	SHELL (1)
17673	RAIL, mounting (quantity=feet)	25546	SCREW, 8-32x1 (1)
17682	CONNECTOR (4)	28718	SWITCH, red pushbutton (2)
17774	MODULE, control (1)	28719	SWITCH, green pushbutton (2)
17780	BRIDGE (2)	28720	SWITCH, clear push/pull (1)
17782	FUSEHOLDER (2)	31701	SPACER (4)



## Electrical – Door Mounted







## Electrical – Door Mounted

PART NO.	PART NAME	PART NO.	PART NAME
09465	LAMP, 24 V (1)	19115	LENS (3)
11514	SCREW, hex head, 10-24x3/8	19128	RING, retaining (3)
13201	COVER (1)	20436	SWITCH, disconnect (1)
13607-129	O-RING (3)	28718	SWITCH, red pushbutton (2)
16221	MODULE, digital gauges (1)	28719	SWITCH, green pushbutton (2)
16222	TRANSDUCER and plug assembly (3)	28720	SWITCH, clear push/pull (1)
16260	CORD and plug assembly (1)	29358	CONTACT BLOCK (2)
18803	BRACKET, mounting (1)	29361	CONTACT BLOCK (2)
18812	BOX (1)	29366	KNOB, clear (1)
18821	DOOR (1)	29367	CONTACT BLOCK (4)
19112	HOUSING, lens (3)		

**YOU ARE HERE:** ►




## Electrical Cords & Connectors




## Electrical Cords & Connectors

PART NO.	PART NAME	PART NO.	PART NAME
02441	NUT (1)	18563	SWITCH assembly (2)
09150	TUBING, plastic, 3/8 (quantity=feet)	18564	MAGNET (5)
11286	MOTOR, 1.5 hp, 575 V (1opt)	18812	BOX (1)
11299	FITTING, 90°: 3/8 tube x 3/8 NPT (1)	18813	PANEL (1)
11380	NUT, hex, 10-24	18821	DOOR (1)
11457	SCREW, slotted round, 10-24x3/4	19062	SWITCH, magnetic (3)
11493	WASHER, lock, internal tooth, #10	19065	NUT (6)
12090	NUT (2)	19091	MOTOR, 5 hp, 380 V/60 (1opt)
12518	MOTOR, 1.5 hp, 415 V (opt)	19315	WIRE, earth, 12 ga (quantity= feet)
14733	EYELET (3)	19459	WATERTIGHT (2)
15288	WATERTIGHT (1)	20888	MOTOR, 1.5 hp, 190-460 V (1opt)
16135	NUT, hex, 10-32	21140	CABLE, 14/4 (quantity=feet)
16221	MODULE, digital gauges (1)	21465	WIRE, earth, 10 ga (quantity=feet)
16222	TRANSDUCER and plug assembly (3)	22154	CABLE, 12/4 (quantity=feet)
16260	CORD and plug assembly (1)	23353	MOTOR, 5 hp 575 V (1opt)
16631	FITTING, straight, 3/8 tube x 1/4 NPT (1)	25452	NUT (1)
17578	MOTOR, 5 hp, 190-460 V (1opt)	25453	GASKET (1)
18559	TAG, earth (5)		




### Air System – Supply




## Air System – Supply

PART NO.	PART NAME	PART NO.	PART NAME
09420	TUBE, plastic, clear (quantity=feet)	15037	TUBE, plastic, red (quantity=feet)
09939	ADAPTER, straight (7)	15039	TUBE, plastic, yellow (quantity=feet)
11376	NUT, hex jam, 3/4-10 (7)	15271	TEE (2)
11786	FITTING assembly, straight (3)	16166	TEE (1)
11787	FITTING, 90° (3)	16167	ADAPTER, quick disconnect (1)
11788	FITTING assembly, 90° (3)	16221	MODULE, digital gauges (1)
11789	ADAPTER, straight (10)	16222	TRANSDUCER & plug assembly (1)
11791	TUBING – STAINLESS (3)	16232	FITTING–90° (3)
13540	FITTING, 90° (10)	19116	PANEL (1)
13541	FITTING, 90° (4)	19118	REGULATOR, pressure (3)
14251	ADAPTER, straight (3)	19521	ELBOW (1)
14687	FILTER assembly (4)	21332	VALVE, quick exhaust (1)
15027	TUBE, plastic, black (quantity=feet)	21334	FITTING, straight (1)
15036	TUBE, plastic, green (quantity=feet)		




## Air system – Circuits







## Air system – Circuits

PART NO.	PART NAME	PART NO.	PART NAME
09420	TUBE, plastic, clear (quantity=feet)	13541	FITTING, 90° (3)
09423	BLOCK (1)	15036	TUBE, plastic, green (quantity=feet)
09930	BLOCK (1)	15037	TUBE, plastic, red (quantity=feet)
09939	FITTING, straight (9)	15039	TUBE, plastic, yellow (quantity=feet)
10742	CYLINDER, assist (2)	16166	TEE (1)
11275	CYLINDER, stripper (2)	16325	FITTING, straight (3)
13412	FITTING, straight (1)	16632	FITTING, 90° (4)
13540	FITTING, 90° (7)	19460	TANK (1)




## Tags






## Tags

PART NO.	PART NAME	PART NO.	PART NAME
10403	TAG—MODEL/SER (1)	14379	RIVET—3/8"GRIP (6)
10694	TAG—PATENT (1)	15510	TAG—ELEC RQMTS (1)
12999	TAG—HIGH VOLT (2)	21692	TAG—REPLACE GUARDS (3)




## Model 11




## Model 11

PART NO.	PART NAME	PART NO.	PART NAME
10101	ELBOW (1opt)	13607-223	O-RING (1opt)
10187	SCREEN, 10 mesh (1)	13875	ELBOW (1opt)
10189	SCREEN, 20 mesh (1)	14060	FLOAT ASM (1)
10191	SCREEN, 30 mesh (6)	14097	TANK (1)
10604	FLOAT (1)	14111	BRACKET, mounting (1)
10605	SCREW, adjustment (1)	14131	ROD (1)
10608	PIN (1)	14132	PANEL (1)
10609	POPPET assembly (1)	14134	HANDLE (1)
10610	FLANGE (1)	14135	COVER (1)
10778	STOPPER (3opt)	14136	ROD (1)
10784	PIN (1)	14156	LEVER (1)
10785	CLEVIS (1)	14158	KNOB (2)
10786	HOUSING, valve (1)	14262	SEALANT, clear
10787	ROD (1)	14276	NUT BAR (1)
11136	STEM (1)	15992	FITTING, elbow (1opt)
11137	CAP (1)	15995	BAFFLE (1opt)
11311	SCREW, hex head, 1/4-20x3/8	15996	SEAL (1opt)
11312	SCREW, hex head, 1/4-20x1/2	17753	FITTING, baffle (1opt)
11313	SCREW, hex head, 1/4-20x5/8	17757	TROUGH (1)
11326	SCREW, hex head, 5/16-18x5/8	22750	PLUG (3opt)
11362	NUT, hex, 1/4-20	23352	FOOT (2)
11369	NUT, jam, 1/4-20	31761	EXTENSION, (1 /RB15)
11422	SETSCREW, socket, 10-24x3/16	31762	EXTENSION, (1 /RB30)
11462	SCREW, slotted round, 10-24x1/2	31767	FITTING, reducer, (1 /RB15)
11798	REPLACEMENT WHEEL (4)	31768	FITTING, elbow, (1 /RB30)
13607-218	O-RING (1opt)		




## Rotary Filter






## Rotary Filter

PART NO.	PART NAME	PART NO.	PART NAME
02699	HOSE (quantity=feet)	14211	SHAFT (1)
03094	OIL, quart (1)	14212	COLLAR (1)
03126	KEY, square (2)	14213	PIN (1)
06067	WRENCH (1)	14215	BLOCK (2)
09939	FITTING (1)	14216	PAN (1)
10705	KEY, square (1)	14217	NUT (1)
11314	SCREW, hex head, 1/4-20x3/4	14222	BASE, frame (1)
11317	SCREW, hex head, 1/4-20x1-1/4	14231	COVER (1)
11327	SCREW, hex head, 5/16-18x3/4	14234	PLATE, end (2)
11335	SCREW, hex head, 5/16-18x2-1/2 (4)	14235-10	FILTER DRUM (.010 inch gap)(1std)
11341	SCREW, hex head, 3/8-16x3/4 (4)	14235-20	FILTER DRUM (.020 inch gap)(1opt)
11343	SCREW, hex head, 3/8-16x1-1/4	14235-25	FILTER DRUM (.025 inch gap)(1opt)
11362	NUT, hex, 1/4-20	14236	SPRING (2)
11376	NUT, hex, 3/4-10	14237	MOTOR, air (1)
11381	NUT, wing, 1/4-20	14238	GEARBOX (1)
11429	SETSCREW, socket, 1/4-20x3/8 (1)	14239	SCREW, slotted round, 10-32x5/16
11463	SCREW, slotted round, 10-32x1/4	14247	SPACER (1)
11464	SCREW, slotted round, 10-32x1/2	14248	KEY, square (1)
11486	WASHER, flat, 1/4	14249	PLATE, backup (1)
11487	WASHER, flat, 1/4	14250	KIT, repair ki, air motor
11488	WASHER, flat, 9/32	14269	TUBE (1)
11489	WASHER, flat, 11/32 (4)	14270	END, tube (2)
11491	WASHER, flat, 3/8	14271	ANGLE (1)
11497	WASHER, lock, 3/8 (4)	14417	BUMPER (1)
11787	FITTING, 90 degree (1)	14683	FILTER/regulator/lubricator assembly (1)
11789	CONNECTOR (1)	14684	REGULATOR (1)
13275	ELEMENT, filter (1)	14685	GAUGE (1)
13411	TUBING, clear (quantity=feet)	14686	LUBRICATOR (1)
13412	FITTING (1)	14687	FILTER assembly (1)
13540	ELBOW (1)	15726	CAP, bearing (2)
13807	SCREW, hex head, M6x10 mm (4)	16167	SOCKET, quick disconnect (1)
14168	TRAY, pivot (1)	16168	PLUG, quick disconnect (2)
14173	PLATE, end (2)	16175	HOSE assembly (1)
14175	SPACER (3)	22859	SCREW, hex head, M8x20 mm (4)
14176	BLADE, wiper, seal (1)	31403	MUFFLER (1)
14182	backup plate	33747	ROD (3)
14183	BLADE, wiper, scrapper (1)	43869	WASHER, flat, 8 mm (12)
14186	BEARING (2)	46416	GEARBOX (1)
14187	PLATE, end (2)	46417	PLATE (1)
14188	BLADE, wiper, seal (1)	46418	GEAR, 22T (1)
14205	GEAR (1)	46419	COUPLING (1)
14210	SHAFT assembly (1)		




## Stripper Stops




14115

## Stripper Stops




PART NO.	PART NAME	PART NO.	PART NAME
<b>14115</b>	<b>STRIPPER STOP ASM (2opt) (includes the following items)</b>		
11921	RUSH ROD (1)	13607-210	O-RING (1)
11922	PISTON (1)	13607-219	O-RING (1)
11928	RUBBER WASHER (1)	14116	PUSH ROD GUIDE (1)
11929	CUSHION HOLDER-BOTTOM (1)	14117	WASHER (2)
11931	CUSHION ASM-7/16" (1)	14118	LOCK NUT (2)
13116	CUSHION ASM-1 1/8" (1)	14119	GUARD / JAM NUT (1 RH only)
13256	RUBBER SLEEVE (1)	14264	WRENCH (1)



## Infeed Tray




PART NO.	PART NAME	PART NO.	PART NAME
13461	PIN—QUICK RELEASE (2)	13564	BUSHING (2)
13464	TUBE WELDMENT (2)	13604	SPACER (4)
13562	ROD (2)	14178	INFEED TRAY ASM (opt)
13563	CAP (2)	14181	SUPPORT (1)

**YOU ARE HERE:**




## Infeed Rollers



PART NO.	PART NAME	PART NO.	PART NAME
11875	ROLLER (11)	11885	INFEED ROLLER ASM (1)
11878	SUPPORT ANGLE (2)	12964	GUARD (1)
11880	FRAME (1)		


**YOU ARE HERE:**

CABINET  
 DRIVE-CONVEYOR  
 DRIVE-PUMP  
 CONVEYOR

HEAD  
 FLUID SYSTEM  
 ELECTRICAL SYSTEM  
 AIR SYSTEM




TAGS  
 MODEL 11  
 EXTRAS

## Exit Table




PART NO.	PART NAME	PART NO.	PART NAME
15369	SUPPORT ANGLE (2)	15458	FRAME (1)
15376	HANDLING TRAY (1)		

**YOU ARE HERE:** ▶



## Casters



PART NO.	PART NAME	PART NO.	PART NAME
11240	HEX NUT (1)	11838	JACKSCREW (1)
11798	REPLACEMENT WHEEL	14879	CASTER (1)
11834	SUPPORT—JACKSCREW (1)	14880	CASTER ASM (4opt)

**YOU ARE HERE:**

CABINET  
 DRIVE—CONVEYOR  
 DRIVE—PUMP  
 CONVEYOR

HEAD  
 FLUID SYSTEM  
 ELECTRICAL SYSTEM  
 AIR SYSTEM


TAGS  
 MODEL 11  
 EXTRAS

## HARDWARE ITEMS

PART NO.	DESCRIPTION	PART NO.	DESCRIPTION	PART NO.	DESCRIPTION
02114	HX NUT, 5/8-11	11332	HX HD SCR, 5/16-18x1-3/4	11372	JAM NUT, 7/16-14
02538	JAM NUT, 3/4-16	11333	HX HD SCR, 5/16-18x2	11373	JAM NUT, 1/2-13
02878	JAM NUT, 3/4-16 (LH)	11334	HX HD SCR, 5/16-18x2-1/4	11374	JAM NUT, 1/2-20
03015	HX HD SCR, 1/2-13x3-1/8	11335	HX HD SCR, 5/16-18x2-1/2	11375	JAM NUT, 5/8-11
03016	SOC HD SCR, 1/2-13x2-1/2	11336	HX HD SCR, 5/16-18x2-3/4	11376	JAM NUT, 3/4-10
04069	FL WA, 3/8	11337	HX HD SCR, 5/16-18x3-1/4	11377	HX NUT, #10-24 (BRASS)
04922	FL WA, 5/16 (HEAVY)	11338	HX HD SCR, 5/16-18x3-1/2	11378	HX NUT, #6-32
05445	HX HD SCR, 5/8-11x2 (FULL)	11339	HX HD SCR, 3/8-16x1/2	11379	HX NUT, #8-32
06154	HX HD SCR, 7/16-14x1-1/2 (GD 8)	11340	HX HD SCR, 3/8-16x5/8	11380	HX NUT, #10-24
06223	GRD 8 SCR, 7/16-14x1-1/4	11341	HX HD SCR, 3/8-16x3/4	11381	WING NUT, 1/4-20
09450	JAM NUT, 7/8-14	11342	HX HD SCR, 3/8-16x1	11382	CAP NUT, 1/4-20
09451	JAM NUT, 7/8-14 (LH)	11343	HX HD SCR, 3/8-16x1-1/4	11383	CAP NUT, 5/16-18
09847	CAP NUT, 7/16-14	11344	HX HD SCR, 3/8-16x1-1/2	11384	SOC HD SCR, 1/4-20x1/2
10340	SOC HD SCR, 3/8-16x5/8 (GD 5)	11345	HX HD SCR, 3/8-16x1-3/4	11385	SOC HD SCR, 1/4-20x5/8
10639	HX HD SCR, 5/16-18x3-3/4	11346	HX HD SCR, 3/8-16x2	11386	SOC HD SCR, 1/4-20x3/4
10911	HX HD SCR, 1/2-20x1-1/2	11347	HX HD SCR, 3/8-16x2-1/4	11387	SOC HD SCR, 1/4-20x1
11240	HX NUT, 3/4-10	11348	HX HD SCR, 3/8-16x2-1/2	11388	SOC HD SCR, 1/4-20x1-1/4
11305	THUMB SCR, 1/4-20x5/8 (A)	11349	HX HD SCR, 3/8-16x2-3/4	11389	SOC HD SCR, 5/16-18x1/2
11310	HX HD SCR, #6-32x1	11350	HX HD SCR, 3/8-16x3	11390	SOC HD SCR, 5/16-18x5/8
11311	HX HD SCR, 1/4-20x3/8	11351	HX HD SCR, 3/8-16x3-1/2	11391	SOC HD SCR, 5/16-18x3/4
11312	HX HD SCR, 1/4-20x1/2	11352	HX HD SCR, 7/16-20x1-1/2	11392	SOC HD SCR, 5/16-18x1
11313	HX HD SCR, 1/4-20x5/8	11353	HX HD SCR, 7/16-14x2	11393	SOC HD SCR, 5/16-18x1-1/4
11314	HX HD SCR, 1/4-20x3/4	11354	HX HD SCR, 1/2-13x1	11394	SOC HD SCR, 5/16-18x1-1/2
11315	HX HD SCR, 1/4-20x7/8	11355	HX HD SCR, 1/2-13x1-1/4	11395	SOC HD SCR, 5/16-18x1-3/4
11316	HX HD SCR, 1/4-20x1	11356	HX HD SCR, 1/2-13x1-1/2	11396	SOC HD SCR, 3/8-16x5/8
11317	HX HD SCR, 1/4-20x1-1/4	11357	HX HD SCR, 1/2-13x1-3/4	11397	SOC HD SCR, 3/8-16x3/4
11318	HX HD SCR, 1/4-20x1-1/2	11358	HX HD SCR, 1/2-13x2-1/2	11398	SOC HD SCR, 3/8-16x1
11319	HX HD SCR, 1/4-20x1-3/4	11359	HX HD SCR, 5/8-11x2	11399	SOC HD SCR, 3/8-16x1-1/4
11320	HX HD SCR, 1/4-20x2	11360	HX HD SCR, 5/16-18x2-3/4 (FULL)	11400	SOC HD SCR, 3/8-16x1-1/2
11321	HX HD SCR, 1/4-20x2-1/4	11361	HX HD SCR, #6-32x1-1/2	11401	SOC HD SCR, 1/2-13x3/4
11322	HX HD SCR, 1/4-20x2-1/2	11362	HX NUT, 1/4-20	11403	SOC HD SCR, #10-24x1/2
11323	HX HD SCR, 1/4-20x4	11363	HX NUT, 5/16-18	11404	SOC HD SCR, #10-24x5/8
11324	HX HD SCR, 5/16-18x3/8	11364	HX NUT, 3/8-16	11405	SOC FL SCR, 1/4-20x1/2
11325	HX HD SCR, 5/16-18x1/2	11365	HX NUT, 7/16-14	11406	SOC FL SCR, 1/4-20x5/8
11326	HX HD SCR, 5/16-18x5/8	11366	HX NUT, 1/2-13	11407	SOC FL SCR, 1/4-20x3/4
11327	HX HD SCR, 5/16-18x3/4	11368	HX NUT, 5/8-11	11408	SOC FL SCR, 1/4-20x1
11328	HX HD SCR, 5/16-18x7/8	11369	JAM NUT, 1/4-20	11409	SOC FL SCR, 1/4-20x1-3/4
11329	HX HD SCR, 5/16-18x1	11370	JAM NUT, 5/16-18	11410	SOC FL SCR, 5/16-18x5/8
11330	HX HD SCR, 5/16-18x1-1/4	11371	JAM NUT, 3/8-16	11411	SOC FL SCR, 5/16-18x1
11331	HX HD SCR, 5/16-18x1-1/2				

## HARDWARE ITEMS

PART NO.	DESCRIPTION	PART NO.	DESCRIPTION	PART NO.	DESCRIPTION
11412	SOC FL SCR, 5/16-18x1-1/4	11442	SOC SETSCR, 3/8-16x5/8	11472	SL RD SCR, 5/16-18x1/2
11413	SOC FL SCR, 5/16-18x1-1/2	11443	SOC SETSCR, 3/8-16x1	11473	SQ SETSCR, 5/16-18x1/2
11414	SL FL SCR, #6-32x3/8	11444	SOC SETSCR, 3/8-16x1-1/4	11474	SQ SETSCR, 5/16-18x5/8
11415	SL FL SCR, # 8-32x1/4	11445	SOC SETSCR, 1/2-13x3/4	11475	SQ SETSCR, 3/8-16x1/2
11416	SL FL SCR, #8-32x5/16	11446	SL RD SCR, #6-32x1/4	11476	BIND SCR, #8-32x3/8
11417	SL FL SCR, #8-32x3/8	11447	SL RD SCR, #6-32x3/8	11477	BIND SCR, #8-32x1/2
11418	SL FL SCR, #10-24x1/2	11448	SL RD SCR, #6-32x3/4	11478	BIND SCR, #8-32x3/4
11419	SL FL SCR, #10-24x5/8	11449	SL RD SCR, #6-32x1-1/2	11479	BIND SCR, #10-32x1/2
11420	SL FL SCR, #10-24x3/4	11450	SL RD SCR, #8-32x1/4	11480	BIND SCR, #10-32x3/4
11421	SOC SETSCR, #10-24x1/8	11451	SL RD SCR, #8-32x3/8	11481	SL PAN SCR, #10-32x1/2
11422	SOC SETSCR, #10-24x3/16	11452	SL RD SCR, #10-24x3/16	11482	FL WA, 1/2
11423	SOC SETSCR, #10-24x1/4	11453	SL RD SCR, #10-24x1/4	11483	SL RD SCR, #10-24x3/8
11424	SOC SETSCR, #10-24x5/16	11454	SL RD SCR, #10-24x5/16	11484	SHT MTL SCR, #8x3/8
11425	SOC SETSCR, #10-24x3/8	11455	SL RD SCR, #10-24x1/2	11485	FL WA #8
11426	SOC SETSCR, #10-24x5/8	11456	SL RD SCR, #10-24x5/8	11486	FL WA #10
11427	SOC SETSCR, 1/4-20x1/4	11457	SL RD SCR, #10-24x3/4	11487	FL WA, 1/4
11428	SOC SETSCR, 1/4-20x5/16	11458	SL RD SCR, #10-24x7/8	11488	FL WA, 1/4
11429	SOC SETSCR, 1/4-20x3/8	11459	SL RD SCR, #10-24x1	11489	FL WA, 5/16
11430	SOC SETSCR, 1/4-20x1/2	11460	SL RD SCR, #10-24x1-1/2	11490	FL WA, 5/16
11431	SOC SETSCR, 1/4-20x3/4	11461	SL RD SCR, #10-24x2	11491	FL WA, 3/8
11432	SOC SETSCR, 1/4-20x1	11462	SL RD SCR, #10-24x2-1/2	11492	FL WA, 3/4
11433	SOC SETSCR, 5/16-20x5/16	11463	SL RD SCR, #10-32x1/4	11493	STAR WA, #10
11434	SOC SETSCR, 5/16-18x3/8	11464	SL RD SCR, #10-32x1/2	11494	LK WA, 1/4
11435	SOC SETSCR, 5/16-18x1/2	11465	SL RD SCR, #10-32x3/4	11495	LK WA, 5/16 (REG)
11436	SOC SETSCR, 5/16-18x5/8	11466	SL RD SCR, 1/4-20x1/2	11496	LK WA, 5/16 (LT)
11437	SOC SETSCR, 5/16-18x3/4	11467	SL RD SCR, 1/4-20x5/8	11497	LK WA, 3/8
11438	SOC SETSCR, 5/16-18x1-1/2	11468	SL RD SCR, 1/4-20x3/4	11498	LK WA, 1/2
11439	SOC SETSCR, 3/8-16x1/4	11469	SL RD SCR, 1/4-20x1	11499	LK WA, 5/8
11440	SOC SETSCR, 3/8-16x5/16	11470	SL RD SCR, 1/4-20-1-1/2	11500	LK WA, 3/4
11441	SOC SETSCR, 3/8-16x3/8	11471	SL RD SCR, 1/4-20x1-3/4	11501	LK WA, #10




## HARDWARE ITEMS

PART NO.	DESCRIPTION	PART NO.	DESCRIPTION	PART NO.	DESCRIPTION
11502	SOC SETSCR, 1/4-20x1/4	12443	HX HD SCR, 1/4-20x2-3/4	14172	SOC HD SCR, 1/4-28x3/4
11503	SOC SETSCR, 1/4-20x1/4 (BLK)	12627	SL RD SCR, #3-48x1/2	14239	SL RD SCR, #10-32x5/16
11504	SOC SETSCR, 5/16-18x1/4	12628	FL WA, #3	14302	FL WA, #6 (BRASS)
11505	SOC SETSCR, 5/16-18x3/8	12629	LK WA, #3	14303	FL WA, 1/2
11506	SOC SETSCR, 3/8-16x1-1/2	12817	SQ SETSCR, 5/16-18x3/4	14335	SL RD SCR, #10-24x1-1/4
11507	HX HD SCR, #10-24x2-1/2	12820	STAR WA, #8	14525	SOC FL HD SCR, #8-32x3/4
11508	SQ SETSCR, 5/16-18x3/8	12880	HX NUT, #3-48	14526	SOC FL SCR, 1/4-20x7/8
11509	HX HD SCR, 1/2-13x3/4	12920	HX HD SCR, 3/8-16x2-1/4 (FULL)	14528	BUT HD SCR, #8-32x1-1/8
11510	HX HD SCR, #6-32x1-3/4	12922	HX HD SCR, #10-32x7/8	14529	BIND HD SCR, #8-32x5/8
11511	STAR WA, #6	13005	SOC SETSCR, 3/8-24x1/2	14690	HX HD SCR, 1/4-20x1-1/8
11512	SL PAN SCR, 1/4-20x3/8	13028	LK NUT, 1/2-20	14735	BUT HD SCR, #8-32x1-1/4
11514	HX HD SCR, #10-24x3/8	13074	SOC SETSCR, 5/16-18x3/8 (BLK)	14736	SOC SETSCR, 1/4-20x3/16 (BLK)
11516	SL PAN SCR, #8-32x1/2	13076	SL RD SCR, #6-32x1-3/4 (ZINC)	14737	SOC SETSCR, 5/16-18x1/4 (BLK)
11517	JAM NUT, 5/8-18	13077	SL RD SCR, #6-32x2 (ZINC)	14738	SOC SETSCR, 3/8-16x1-1/4 (BLK)
11519	SHT MTL SCR, #8x1/2	13078	SOC SETSCR, 1/4-20x5/16 (BLK)	14739	HX HD SCR, #10-24x1/2
11520	SHT MTL SCR, #8x5/8	13079	SOC SETSCR, 1/4-20x3/8 (BLK)	14740	LK NUT, #10-32
11521	SHT MTL SCR, #10x1	13080	SOC SETSCR, #10-24x3/8 (BLK)	14741	LK NUT, #8-32
11522	SL RD SCR, #6-32x1	13081	HX NUT, #6-32	14742	FL WA, #10
11523	FL WA, #6	13233	SOC FL SCR, #10-24x3/4	14743	BUT HD SCR, #8-32x3/4
11524	HX HD SCR, #10-24x5/8	13285	THUMB SCR, 1/4-20x3/8 (A)	14761	SOC SETSCR, 1/4-20x3/16
11525	HX HD SCR, #10-24x1	13385	LK NUT, 1/4-20	14777	SOC FL SCR, #10-24x7/8
11526	SL PAN SCR, #10-24x1/4	13406	JAM NUT, 5/16-24	14843	SOC SETSCR, #6-32x1/4
11527	SL PAN SCR, #10-24x1/2	13427	SL RD SCR, #4-40x1	14881	HX HD SCR, 1/4-20x1-3/8
11528	FL WA, 3/4	13433	SOC SETSCR, 1/4-20x1/8	15116	LK WA, 7/16
11530	SL FL SCR, 1/4-20x1/2	13451	SOC HD SCR, #10-32x1-1/2 (BLK)	15117	FL, WA, 7/16
11542	SOC HD SCR, 3/8-24x1	13542	SL RD SCR, #10-24x1-1/4	15138	HX HD SCR, M6x1x12mm
11575	SOC HD SCR, #10-24x7/8	13557	SOC SETSCR, 5/16-24x1/2	15144	SOC HD SCR, M6x1x20mm
11587	HX HD SCR, 1/4-20x2-1/2 (FULL)	13566	BUT HD SCR, #10-24x3/4	15145	FL WA, 3/8
11588	THUMB SCR, 1/4-20x1/2 (B)	13597	SOC SETSCR, 1/4-20x5/16 (LK)	15157	HX HD SCR, 7/16-14x1-1/2
11660	SOC SETSCR, #10-24x1/2	13608	SOC HD SCR, #10-32x1-3/8	15193	BIND SCR, #8-32x1-1/4
11693	SL RD SCR, #6-32x2	13677	SOC HD SCR, #8-32x3/8	15201	FL WA, 5/8
11694	SL RD SCR, #6-32x1-3/4	13807	HX HD SCR, M6x1x10mm	15230	SOC SETSCR, M10x1.5x80mm
11712	STAR WA, 1/4	13855	FILL HD SCR, 1/4-20x2	15231	SOC HD SCR, M10x1.5x70mm (BLK)
11792	SOC SETSCR, #10-32x1/4	13881	SL PAN SCR, #10-32x3/8	15311	SOC HD SCR, #10-32x3/4
11980	SOC HD SCR, #6-32x1/2	13909	HX HD SCR, #10-24x3/4	15312	SOC HD SCR, #8-32x5/8
12029	SOC HD SCR, #6-32x1/4 (FULL)	14021	SOC SETSCR, #8-32x5/16	15338	HX HD SCR, M8x1.25x35mm
12033	HX HD SCR, #10-24x1-1/4	14125	SL RD SCR, #4-40x3/16	15340	SOC SETSCR, 5/16-18x5/16 (LK)
12055	SHT MTL SCR, #10x3/8	14127	SL FL SCR, #10-24x3/8	15341	SOC SETSCR, #8-32x3/8
12081	HX HD SCR, 1/4-20x3	14130	SL FL SCR, #6-32x3/16	15342	SOC SETSCR, 1/4-20x5/16 (BLK)

## HARDWARE ITEMS

PART NO.	DESCRIPTION	PART NO.	DESCRIPTION	PART NO.	DESCRIPTION
15343	SOC SETSCR, 1/4-20x3/8 (BLK)	16126	HX HD SCR, 3/8-16x7/8	17468	SOC HD SCR, #10-32x1/2
15344	SOC HD SCR, 1/4-20x3/8	16127	SOC FL SCR, 5/16-18x3/4	17481	SQ HD SETSCR, 3/8-16x1
15345	HX HD SCR, 5/16-18x3	16128	HX HD SCR, 1/4-28x3/8	17636	SL FL SCR, #10-32x1
15346	HX HD SCR, M8x1.25x40mm (FULL)	16129	HX HD SCR, 5/16-18x2-1/8	17729	HX HD SCR, 5/16-18x5-1/2
15388	FL WA, 5/8	16130	SOC SETSCR, 1/4-20x1/2 (BLK)	17883	HX HD SCR, 5/16-24x7/8
15393	SL RD SCR, #8-32x1	16131	LK NUT, M6x1 (BLK)	17899	HX HD SCR, 3/8-24x1-3/4
15395	SOC FL SCR, #8-32x1/2	16132	SOC SETSCR, M6x1x45mm (BLK)	17901	HX HD SCR, 5/16-24x1
15409	SOC HD SCR, #4-40x1/4	16133	SOC SETSCR, 3/8-16x1-1/8	17908	HX HD SCR, 3/8-24x7/8
15460	SOC SETSCR, 5/16-18x1/2 (BLK)	16134	SOC HD SCR, #8-32x3/4	17913	SOC FL SCR, 1/4-28x5/8
15481	BIND SCR, #10-32x3/8	16135	HX NUT, #10-32	17919	HX HD SCR, 3/8-24x1
15482	BUT HD SCR, #10-24x1	16164	SOC HD SCR, 1/4-20x1/4	17993	SOC SETSCR, 1/4-20x5/16(nyltip)
15483	SOC HD SCR, #6-32x5/8 (BLK)	16292	SOC FL SCR, 3/8-24x1	18025	HX HD SCR, 3/8-24x2-1/4
15484	HX HD SCR, 3/8-16x2-1/4 (FULL)	16301	SOC HD SCR, 5/16-18x2	18027	HX HD SCR, 1/4-28x3/4
15549	CAP NUT, 3/8-16	16338	HX HD SCR, M8x35mm	18052	HX HD SCR, 5/16-24x1/2
15554	HX NUT, M8x1.25	16343	FL WA, 13/64	18067	HX HD SCR, 1/4-28x1-3/4
15555	HX HD SCR, M8x1.25x30mm	16393	HX HD SCR, 3/8-24x1	18075	HX HD SCR, 1/4-28x1-1/4
15586	HX HD SCR, 3/8-16x1-3/4 (FULL)	16394	HX HD SCR, 5/16-24x3/4	18084	HX HD SCR, 3/8-24x1-1/4
15600	LK NUT, 5/16-18	16405	HX HD SCR, 5/16-24x1/2	18091	HX HD SCR, 3/8-24x3/4
15635	SL RD SCR, #6-32x2-1/4	16410	SL FL SCR, #10-32x1/4	18111	LK NUT, 7/16-20
15636	SOC FL SCR, #8-32x1/4	16413	SOC HD SCR, 7/16-20x1	18114	HX NUT, 1-3/4-20
15641	SOC HD SCR, M10x1.5x40mm	16617	FILL HD SCR, 5/16-18x3/8	18125	HX HD SCR, 1/4-28x7/8
15677	BIND SCR, #8-32x5/16	16645	SOC HD SCR, #10-32x1	18132	HX HD SCR, 1/4-28x1/2
15690	SOC HD SCR, 1/2-13x3	16725	SL FL SCR, 1/4-20x7/8	18143	HX HD SCR, 1/4-28x5/8
15725	BIND SCR, #8-32x11/16	16914	HX HD SCR, 5/16-24x1-3/4	18209	SL FL SCR, 3/8-16x1
15749	HX HD SCR, 1/2-13x5-3/4	16915	HX HD SCR, 1/4-28x1	18218	SL FL SCR, #10-32x1/2
15791	HX HD SCR, M8x1.25x16mm	16920	HX HD SCR, #10-32x1-1/2	18331	SOC FL SCR, 3/8-16x1
15792	SOC HD SCR, M6x1x12mm	16930	SL PAN SCR, #8-32x1/2	18473	SOC FL SCR, #8-32x3/8
15890	SOC SETSCR, 1/4-20x5/16 (LK)	17072	HX HD SCR, 3/8-16x5-1/2	18539	HX HD SCR, 1/2-20x1-1/2
15968	HX HD SCR, 5/16-18x4	17343	SOC HD SCR, #8-32x1-1/4	18557	BIND SCR, #8-32x1-1/2
16125	CAP NUT, 5/16-18	17467	SL FL SCR, #10-32x7/8	18640	HX HD SCR, 5/16-24x5/8






## HARDWARE ITEMS

PART NO.	DESCRIPTION	PART NO.	DESCRIPTION	PART NO.	DESCRIPTION
18646	HX HD SCR, #10-32x3/8	22847	HX HD SCR, M5x0.8x8mm	22886	HEX NUT, M5x0.8
18647	SOC HD SCR, 3/8-24x3/4	22848	HX HD SCR, M5x0.8x10mm	22887	HEX NUT, M10x1.5
18648	SL FL SCR, #8-36x5/8	22849	HX HD SCR, M5x0.8x12mm	22888	HEX NUT, M12x1.75
18661	SL FL SCR, 1/4-28x5/8	22850	HX HD SCR, M5x0.8x14mm	22889	HEX NUT, M14x2
18666	HX HD SCR, 1/4-28x2-1/4	22851	HX HD SCR, M5x0.8x16mm	22890	HEX NUT, M16x2
18773	HX HD SCR, 3/8-24x5/8	22852	HX HD SCR, M5x0.8x18mm	22891	SL FL SCR, M5x16mm
18791	SL FL SCR, #8-32x1-3/4	22853	HX HD SCR, M6x1.0x14mm	22915	SOC HD SCR, 3/8-18x3-1/4
18793	HX NUT, 18mm	22854	HX HD SCR, M6x1.0x16mm	22923	HX NUT, 1/2-13 (NYLOK)
18819	SL FL SCR, #8-32x5/8	22855	HX HD SCR, M6x1.0x20mm	22956	PAN HD SCR, M4x0,7x6mm
18917	HX HD SCR, 10-32x1/2	22856	HX HD SCR, M6x1.0x25mm	22977	HX HD SCR, 1/2-13x2
20031	HX HD SCR, 1/2-13x4	22857	HX HD SCR, M8x1.25x12mm	23384	PAN HD SCR, M5x0.8x16mm
18936	HX HD SCR, M4x0.7x8mm	22858	HX HD SCR, M8x1.25x14mm	23432	SOC HD SCR, M6x1.0x45mm
19140	SOC HD SCR, #4-40x3/8	22859	HX HD SCR, M8x1.25x20mm	23433	HX HD SCR, M6x1.0x30mm
19253	HX HD SCR, 3/8-24x1-1/2	22860	HX HD SCR, M8x1.25x25mm	23481	WING SCR, M6x1.0x20mm
19316	SOC SETSCR, 1/4-28x1/4	22861	HX HD SCR, M10x1.5x16mm	23554	HX HD SCR, M6x1.0x35mm
19398	HX HD SCR, 3/8-24x1-3/8	22862	HX HD SCR, M10x1.5x20mm	23906	FL WA, 5/16
19399	SOC HD SCR, 1/4-28x1/2	22863	HX HD SCR, M10x1.5x25mm	24283	SOC SETSCR, M6 x 30mm
19403	PAN HD SCR, M4x0,7x10mm	22864	HX HD SCR, M10x1.5x30mm	24284	SOC SETSCR, M6 x 6mm
19595	HX HD SCR, 5/16-24x1-1/4	22865	HX HD SCR, M10x1.5x35mm	24289	SL FL SCR, M8 x 16mm
19814	HX HD SCR, 5/16-24x2-1/4	22866	HX HD SCR, M10x1.5x40mm	24471	SL FL SCR, M6 x 12mm
20388	PAN HD SCR, 8-32x1-1/2	22867	HX HD SCR, M12x1.75x16mm	24629	CAP NUT, M8
20722	HX HD SCR, 1/2-20x1-1/2 Grade 8	22868	HX HD SCR, M12x1.75x20mm	25431	CAP NUT, M12
21168	HX NUT, 3/8-16 (LK)	22869	HX HD SCR, M12x1.75x25mm	25433	SOC HD SCR, M10 x 20mm
21260	SL FL SCR, #10-32x3-1/4	22870	HX HD SCR, M12x1.75x30mm	25448	SL SETSCR, M6 x 12mm
21261	SL FL SCR, #10-32x1-1/2	22871	HX HD SCR, M12x1.75x35mm	25616	CAP NUT, M6
21657	SL RD SCR, #4-40x1/2	22872	HX HD SCR, M12x1.75x40mm	25638	HX HD SCR, M6 x 50mm
22088	SOC HD SCR, M4x0.7x20mm	22873	HX HD SCR, M14x2x25mm	25720	CAP NUT, M4
20781	SOC HD SCR, M6x1.0x30mm	22874	HX HD SCR, M14x2x30mm	25874	JAM NUT, 7/16-20
22491	SOC HD SCR, 8-32x1	22875	HX HD SCR, M14x2x35mm	25945	SL FL SCR, M6 x 16mm
22533	HX HD SCR, M6x1.0x6mm	22876	HX HD SCR, M14x2x40mm	26163	SOC HD SCR, M8 x 30mm
22534	BIND HD SCR, M3x0.5x6mm	22877	HX HD SCR, M14x2x45mm	26165	SL FL SCR, M4 x 12mm
22763	BIND SCR, M5x0.8x10mm	22878	HX HD SCR, M14x2x50mm	26188	HX HD SCR, M8 x 70mm
22767	HX HD SCR, M8x1.25x45mm	22879	HX HD SCR, M16x2x25mm	26212	SL FL SCR, M10 x 40mm
22768	HX HD SCR, M6x1.0x8mm	22880	HX HD SCR, M16x2x30mm	26213	CAP NUT, M10
22769	SL FL SCR, M6x1.0x20mm	22881	HX HD SCR, M16x2x35mm	26431	HX HD SCR, M10 x 70mm
22774	PAN HD SCR, M6x1.0x16mm	22882	HX HD SCR, M16x2x40mm	26432	LK NUT, M10
22775	WING SCR, M6x1.0x12mm	22883	HX HD SCR, M16x2x50mm	26433	HX NUT, M4
22776	WING SCR, M6x1.0x30mm	22884	HX HD SCR, M16x2x60mm	26503	SOC HD SCR, 1/4-20 x 1-1/2
22777	SOC HD SCR, M6x1.0x30mm	22885	HX NUT, M6x1.0	26504	SOC HD SCR, M8 x 16mm
22794	SOC SETSCR, M6x1.0x8mm				



## HARDWARE ITEMS

PART NO.	DESCRIPTION	PART NO.	DESCRIPTION	PART NO.	DESCRIPTION
26540	SOC FL SCR, M8 x 16mm				



**A**

- Air Motor (rotary filter)
  - controlling, 23,31
  - parts list, 157
- Air System
  - air supply, 19
  - diagram, 91
  - operation, 31,33
  - parts list
    - circuits, 151
    - supply, 149
  - setting pressures, 23
- Airborne Noise, 7
- Amperage
  - motor usage, 17
- Assist Cylinder
  - maintenance, 77
  - parts list, 127
  - setting pressure, 23,31

**B**

- Belt
  - conveyor, 73,119,123
  - conveyor drive, 67,113
- Bleed Valve
  - cause of air in fluid, 63
  - operation, 25,31,32
  - parts list, 133,135

**C**

- Cabinet
  - parts list, 109,111
- Casters
  - parts list, 163
- Chain
  - conveyor, 73,119,123
  - drive, 67,113
- Cleaning
  - cleaning agents, 43
  - pressure used, 41,43
  - procedure
    - removing soil, 39
    - sanitizing, 45
  - safety during, 39
  - start of section, 37
  - temperature used, 39,41,43

**D**

- Clutch, 75,119,123
- Control Switch, 29,145
- Control Valve
  - adjustment, 59
  - parts list, 129,131
  - valve insert, 59
- Controls, 29,31
- Conveyor
  - general description, 15
  - maintenance
    - belt & brake, 73
    - clutch, 75
    - drive belt & chain, 67
    - drive shafts & bearings, 71
    - replace drive motor, 69
  - needle overlap pattern, 56
  - parts list
    - guards (metal belt), 121
    - guards (plastic belt), 125
    - metal belt, 119
    - plastic belt, 123
    - speeds, 57
    - variable stroke linkage, 31,57
- Conveyor Belt, 73,119,123
- Conveyor Drive
  - parts list, 113
- Countershaft Replacement, 71
- Crankshaft Replacement, 71
- Cross Reference
  - how to use, 102
  - list, 104

- Dimensions
  - installation, 16
- Drainage
  - fluid system, 19
- Drive
  - conveyor
    - belt & chain, 67
    - parts list, 113
    - replace motor, 69
    - shafts & bearings, 71
    - speeds, 57
  - pump
    - alignment, 89
    - parts list, 117
    - replace motor, 89
  - variable stroke linkage, 57
- Drive Belt, 67,113
- Drive Chain, 67,113
- Drive Start Switch, 29,145
- Drive Stop Switch, 29,145

**E**

- Electrical
  - cleaning, 43
  - daily safety check, 25
  - diagrams, 94
  - lock out (supply voltage), 55
  - lock out supply, 8
  - parts list
    - cords & connectors, 147
    - main panel, 143
    - parts mounted in door, 145
  - requirements, 17
  - safety hazard, 55
- Exit Table
  - parts list, 162

**F**

- Filter
  - cleaning, 39
  - parts list
    - rotary filter, 157
    - tank, 155
  - screens, 65
  - setting air pressure, 23,31
- Fluid Hoses
  - parts list
    - RB10/15 large, 139

RB10/15 small, 137  
RB30, 141

Fluid Supply  
general requirements,  
19

Fluid System  
control valve,  
59,129,131,137,139,1  
41  
diagram, 93  
drainage, 19  
filter screens, 65  
general description, 15  
hoses, 63,137,139,141  
rotary filter, 157  
setting pressure, 23,31

## G

General  
description of machine,  
15  
factors affecting opera-  
tion, 32  
maintenance, 54

## H

H1, H2 lubricants, 52

Head & Valve  
maintenance  
assist cylinders, 77  
head alignment, 77  
stripper, 79,81  
stripper cylinders, 81  
valve adjustment, 59  
parts list  
RB10/15, 129  
RB30, 131

Head Carriage  
maintenance, 77  
parts list, 127

## I

Infeed Rollers  
parts list, 161

Infeed Tray  
parts list, 160

Injection Percentages,  
19,23,31,57

Installation  
assembly & start—up, 21  
daily safety check, 25  
description of machine,  
15  
overall dimensions, 16  
start of section, 13  
utility requirements, 17  
air supply, 19  
drainage, 19  
electrical, 17  
fluid supply, 19

## L

Lock Out (supply voltage),  
55

Lubricants, 50

Lubrication  
USDA requirements, 52

Lubrication Instructions, 51

## M

Machine Controls, 29,31

Main Disconnect Switch,  
29,145  
lock out, 11

Maintenance  
assist cylinders, 77  
control valve, 59  
conveyor  
belt & brake, 73  
clutch, 75  
drive belt & chain, 67  
drive shafts & bearings,  
71  
replace drive motor, 69  
drive belt, 67  
drive chain, 67  
electrical system, 94  
filter, 65

fluid hoses, 63  
general guidelines, 54  
head carriage, 77  
health risks during, 54  
lubrication, 51  
USDA, 52  
preserve original design,  
54,55  
preventive, 49  
pump  
bearing housing, 87  
preventive, 83  
wear sleeves, 85  
seals and bearings, 54  
self locking fasteners, 54  
start of section, 47  
stripper, 79,81  
stripper cylinders, 81  
stripper stops, 61  
technical assistance, 55  
variable stroke linkage, 57

Model 11

choice of screens, 65  
cleaning, 39  
operation, 32  
parts list  
rotary filter, 157  
tank, 155  
precautions, 21  
setting air pressure, 23,31

Motor

amperage, 17  
overload protection  
conveyor, 69  
pump, 89  
parts list, 113,117,147  
conveyor drive, 113  
pump drive, 117  
replacement  
conveyor drive, 69  
pump drive, 89  
rotation  
conveyor, 23,69  
pump, 89

## N

Needle

cleaner, 131  
cleaning, 41  
puller, 131

Needle Overlap Pattern, 56

Noise, 7

## O

### Operation

- assembly & start-up, 21
- bleed valve, 25,31,32
- factors affecting, 32
- fluid filter, 32
- general variables, 33
- machine controls, 29,31
- product variables, 33
- start of section, 27

Overall Dimensions, 16

## P

### Parts List

- air circuits, 151
- air supply, 149
- assist cylinder, 127
- bleed valve, 133,135
- cabinet, 109,111
- casters, 163
- conveyor drive, 113
- electrical
  - cords & connectors, 147
  - main panel, 143
  - mounted in door, 145
- exit table, 162
- fluid hoses (RB10/15 large), 139
- fluid hoses (RB10/15 small), 137
- fluid hoses (RB30), 141
- guards (metal conveyor belt), 121
- guards (plastic conveyor belt), 125
- head & valve (RB10/15), 129
- head & valve (RB30), 131
- head carriage, 127
- infeed rollers, 161
- infeed tray, 160
- metal conveyor belt, 119
- Model 11 rotary filter, 157
- Model 11 tank, 155
- plastic conveyor belt, 123
- pump (RB10/15), 133

- pump (RB30), 135
- pump drive, 117
- rotary filter, 157
- start of section, 101
- stripper & cylinder, 127
- stripper stops, 159
- tags & labels, 153
- valve (RB10/15), 129
- valve (RB30), 131
- variable stroke linkage, 115

Power Switch, 145

### Pressure

- air system, 23
- fluid, 23,31

Preventive Maintenance, 49

### Product

- delicate, 61

### Pump

- maintenance
  - bearing housing, 87
  - preventive, 83
  - replace motor, 89
  - wear sleeves, 85
- parts list
  - RB10/15, 133
  - RB30, 135

### Pump Drive

- maintenance
  - alignment, 89
  - motor, 89
- parts list, 117

Pump Start Switch, 29,145

Pump Stop Switch, 29,145

## R

### RB10/15

- filter screens, 65
- fittings, 64
- hoses, 63
- maintenance
  - bearing housing, 87
  - preventive, 83
  - wear sleeves, 85
- parts list, 129,133,137,139
- valve adjustment, 59

### RB30

- filter screens, 65
- fittings, 64

hoses, 63

### maintenance

- bearing housing, 87
- preventive, 83
- wear sleeves, 85
- parts list, 131,135,141
- valve adjustment, 59

### Rear Tray

- parts list, 162

### Regulator

- air system, 31

### Repair Parts

- how to order, 103
- how to use parts lists, 102

## S

### Safety

- airborne noise, 7
- being informed, 7,8
- daily safety check, 25
- during cleaning, 39
- during maintenance, 55
- electrical hazard, 8,55
- general description of system, 15
- physical precautions, 8,10
- preserve original design, 54,55
- specification sheet, 11
- start of section, 5,7
- supervisor's responsibilities, 7,9
- technical assistance, 7,55
- what not to do, 10
- what to do, 9

### Schematic

- air system, 91
- electrical system, 94
- fluid system, 93

### Screens

- cleaning, 39

### Stripper

- maintenance, 79,81
- parts list, 127
- stripper stops, 61,159

### Stripper Cylinder

- maintenance, 81
- parts list, 127
- setting pressure, 23,31

### Stripper Stops

- adjustment, 23,61

parts list, 159  
Switches, 143,145,147

## T

Table  
  rear  
    parts list, 162  
Table of Contents, 3  
Tags & Labels  
  cleaning, 43  
  parts list, 153  
Troubleshooting, 97  
  start of section, 95

## U

USDA lubrication require-  
  ments, 52  
Utility Requirements, 17

## V

Valve  
  adjustment, 59  
Valve & Head  
  parts list  
    RB10/15, 129  
    RB30, 131  
Variable Stroke Linkage,  
  31,57  
  parts list, 115

## W

Wheels  
  parts list, 163

